

**Installation
Guide**

hp StorageWorks Director 2/64

Product Version: FW v06.xx/HAFM SW v08.02.00

Fourth Edition (July 2004)

Part Number: AA-RSNGD-TE/958-000289-002

This guide provides procedures for setting up, configuring, and managing the HP StorageWorks Director 2/64.



© Copyright 2001–2004 Hewlett-Packard Development Company, L.P.

Hewlett-Packard Company makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

This document contains proprietary information, which is protected by copyright. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of Hewlett-Packard. The information contained in this document is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

IBM® and AIX are trade marks or registered trade marks of IBM.

Intel® is a U.S. registered trademark of Intel Corporation.

Intel® is a trademark or registered trademark of Intel Corporation in the U.S. and other countries and are used under license.

Java is a trademark of Sun Microsystems, Inc

Linux is a U.S. registered trademark of Linus Torvalds.

Microsoft®, Windows 98®, Windows 2000®, Windows 2003®, Windows XP®, Windows ME®, and Windows NT® are U.S. registered trademarks of Microsoft Corporation.

Red Hat is a registered trademark of Red Hat, Inc.

Sun, Sun Microsystems, the Sun Logo, and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc.

UNIX® is a registered trademark of The Open Group.

Hewlett-Packard Company shall not be liable for technical or editorial errors or omissions contained herein. The information is provided “as is” without warranty of any kind and is subject to change without notice. The warranties for Hewlett-Packard Company products are set forth in the express limited warranty statements for such products. Nothing herein should be construed as constituting an additional warranty.

Printed in the U.S.A.

Director 2/64 Installation Guide
Fourth Edition (July 2004)
Part Number: AA-RSNGD-TE/958-000289-002

Contents

About this Guide	11
Overview	12
Intended audience	12
Related documentation	12
Conventions	13
Document conventions	13
Text symbols	13
Equipment symbols	14
Rack stability	15
Getting help	16
HP technical support	16
HP storage web site	16
HP authorized reseller	16
1 Overview	17
Director Description	18
Features	18
Director Management	19
Error-Detection, Reporting, and Serviceability	20
Zoning	22
Multi-Switch Fabrics	22
Hardware Components	24
Front View	24
CTP2 Card	25
Front Bezel	26
Cable Management Assembly	26
Power Supplies	26
UPM Card	27
Rear View	29
Fan Modules	29

SBAR Assembly	30
Power Module Assembly.....	30
Tools and Test Equipment	31
Tools Supplied with the Director.....	31
Tools Supplied by Service Personnel.....	33
Optional Kits.....	34
2 Installing and Configuring the Director.....	35
Installation Options.....	36
Review Installation Requirements	37
Items Required for Installation.....	38
Select an Operating Location.....	39
Cooling and Power Requirements	39
Unpack and Inspect the Director	40
Install the Director in a Rack	46
Required Tools.....	46
Tips for Installing More than One Switch	46
Transfer the Director to the Lift Device.....	46
HP 9000, HP 10000, and HP 11000 Series Rack Installation	47
Install the Shelf Brackets in a HP 9000, HP 10000, and HP 11000 Series Rack ...	47
Prepare the Switch for Installation	48
Secure the Mounting Hardware	49
Insert the Cage Nuts	50
Insert the Front Cage Nuts in the Rack	50
Insert the Rear Cage Nuts in the Rack	51
Finalize the Rack-Mounting Procedure.....	51
HP System/e and Industry-Standard 19-inch Rack Installation.....	54
Install the Anti-tip Feet on an HP System/e Rack.....	54
Install Mounting Bracket Hardware in the Rack.....	55
Prepare the Front and Rear Rack Columns	59
Prepare the Switch for Installation	60
Finalize the Rack-Mounting Procedure.....	61
Sliding Shelf Installation—For an HAFM Appliance only.....	64
Recommended Cable Management.....	67
Power-On Self Test	68
Configure Director Network Information.....	70
Default Settings	70
Changing the Director's IP Address	71
LAN-Connect the Director.....	77

HAFM Appliance	78
Element ManagerEnabling HAFM to Manage the Director	78
Verify Communication Between the Director and HAFM Appliance.	79
Set Director Date and Time	81
Set Date and Time Manually.	82
Synchronize Date and Time	82
Frequently Used HAFM Settings	84
Setting the Director Online	85
Setting the Director Offline	85
Configuring Director Identification	85
Configuring Director Management Style.	86
Configuring Switch Parameters	87
Switch Parameters	88
Domain ID.	88
Preferred	88
Insistent.	89
Rerouting Delay	89
Domain RSCNs.	90
Suppress RSCN's on Zone Set Activations	90
Director Speed.	91
Configuring Fabric Parameters	91
Fabric Parameters	92
BB_Credit	92
R_A_TOV	92
E_D_TOV	92
Switch Priority	93
Interop Mode.	93
Configuring Preferred Path	94
Configuring Switch Binding	94
Configuring Ports	94
Configuring Port Addresses (FICON)	96
Configuring SNMP Trap Message Recipients.	96
Configuring and Enabling E-mail Notification	97
Configuring and Enabling Call-Home Features.	100
Configuring and Enabling Ethernet Events	100
Configuring Threshold Alerts	101
Creating New Alerts	101
Modifying Alerts	106

Activating or Deactivating Alerts	106
Deleting Alerts.	107
Backing Up HAFM Configuration Data	107
Configuring Open Systems Management Server.	107
Configuring FICON Management Server	107
Configuring Feature Key	107
Configuring Open Trunking.	108
Enabling Embedded Web Server.	108
Enabling Telnet	108
Connecting Cables to the Fibre Channel Ports.	109
Connecting the Director to a Fabric	110
Unpacking, Inspecting, and Installing the Ethernet Hub (Optional)	111
Using HAFM from a Remote Location	112
Remote Workstation Minimum Requirements	112
Installing HAFM Client on a Remote Workstation	113
Launching HAFM from the Remote Client.	114
3 Managing Firmware Versions	117
Determining a Director Firmware Version.	118
Adding a Firmware Version	119
Modifying a Firmware Version Description.	121
Deleting a Firmware Version	122
Downloading a Firmware Version to a Director	123
Backing Up the Director's Configuration.	126
A Regulatory Compliance Notices	127
Regulatory Compliance ID Numbers	128
Federal Communications Commission Notice	128
Class A Equipment.	129
Class B Equipment.	129
Declaration of Conformity for Products Marked with FCC Logo—United States Only	129
Modifications	130
Network and Serial Cables.	130
IEC EMC Statement (Worldwide)	130
Spécification ATI Classe A (France)	130
Canadian Notice (Avis Canadien)	131
Class A Equipment.	131
Class B Equipment.	131
European Union Notice	131

Japanese Notice	132
Harmonics Conformance (Japan)	132
German Noise Declaration	132
Laser Safety	133
Certification and Classification Information	133
Declaration of Conformity	134
B Technical Specifications	135
Physical Dimensions.	136
Environmental Specifications.	136
Power Requirements.	137
Operating Tolerances	137
Laser Information	137
C Electrostatic Discharge.	139
Precautions Against Electrostatic Discharge	140
Grounding Methods	140
Index	141
Figures	
1 Director components—front	25
2 UPM card LEDs and connectors	28
3 Director components—rear	29
4 Torque tool and hex adapter.	31
5 Loopback plug	32
6 Fiber-Optic protective plug	32
7 Null modem cable	33
8 Carton contents for a Director 2/64	41
9 Carton contents for an HP 9000, HP 10000, and HP 11000 Series Rack	42
10 Carton contents for a HP system/e or industry-standard 19-in rack installation	44
11 Securing shelf brackets	49
12 Securing the two mounting brackets	50
13 Aligning the switch in the rack	52
14 Securing the rear angle brackets	53
15 AC power connections.	54
16 Mounting anti-tip feet for a HP system/e rack.	55
17 Rail tray mounting location requirement	56
18 Attaching a rear rail tray bracket	57

19	Installing a Tinnerman nut on the rack-front rail in U1	57
20	Inserting the rail tray in the rack	58
21	Preparing the front rack columns	59
22	Preparing the rear rack columns.	60
23	Installing the rack-mounting brackets on the switch	61
24	Positioning the switch in the rack	62
25	Securing the switch to the rack	63
26	AC power connections	63
27	Installing the sliding shelf brackets	65
28	Positioning the sliding shelf bracket on a rail rear slot	66
29	Positioning the sliding shelf bracket at the rack front	67
30	Recommended cable management.	68
31	Connecting the null modem cable between the director and a workstation.	72
32	Connection Description dialog box	73
33	Connect To dialog box.	73
34	COMn Properties dialog box	74
35	HyperTerminal window	75
36	HyperTerminal dialog box (1)	75
37	HyperTerminal dialog box (2)	76
38	LAN-connect the director	77
39	Discover Setup dialog box	78
40	Domain Information dialog box (IP Address page).	79
41	Hardware View page (with FRU failures).	81
42	Configure Date and Time dialog box.	82
43	Date and Time Synced dialog box	83
44	Configure Identification dialog box.	86
45	Configure Switch Parameters dialog box.	88
46	Configure Fabric Parameters dialog box	91
47	Configure Ports check boxes	95
48	Configure SNMP dialog box	97
49	E-Mail Event Notification Setup dialog box	98
50	HA/SM 8 Server Users dialog box	99
51	Define Filter dialog box	99
52	Configure Ethernet Event dialog box.	100
53	Configure Threshold Alerts dialog box	102
54	New Threshold Alerts dialog box—first screen.	102
55	New Threshold Alerts dialog box—second screen	103
56	New Threshold Alerts dialog box—third screen	104

57	New Threshold Alerts dialog box—summary screen	105
58	Configure Threshold Alerts dialog box	105
59	Connect the Fibre Channel cables	109
60	Port Properties dialog box	110
61	HAFM remote client install	113
62	HAFM 8 Log In dialog box	114
63	View All - HAFM 8 window	115
64	Director Firmware Library dialog box	118
65	New Firmware Version dialog box	120
66	New Firmware Description dialog box	120
67	Backup and Restore Configuration dialog box	124

Tables

1	Document conventions	13
2	Director Optional Kits	34
3	Shipping Carton Contents for a Director 2/64	41
4	Shipping Carton Contents for an HP 9000, HP 10000, and HP 11000 Series Rack	42
5	Parts for Installing in an HP System/e and Industry-Standard 19-inch Rack	45
6	Director Operational States and Symbols	80
7	Dimensions	136
8	Environmental Specifications	136
9	Power Requirements	137
10	Operating Tolerances	137
11	Laser specs - 2 Gb	138

About this Guide

This guide provides information on installing, configuring, managing, and verifying operation of the HP StorageWorks Director 2/64. The Director switch connects storage devices, hosts, and servers in a SAN. The director is easily managed and configured to optimize the performance of your SAN.

“About this Guide” topics include:

- [Overview](#), page 12
- [Conventions](#), page 13
- [Rack stability](#), page 15
- [Getting help](#), page 16

Overview

This section covers the following topics:

- [Intended audience](#)
- [Related documentation](#)

Intended audience

This guide is part of a documentation set that supports the Director. It is intended for use by trained service and installation representatives experienced with the SAN technology and Fibre Channel technology.

Related documentation

For a list of corresponding documentation included with this product, see the Related Documents section of the *HP StorageWorks Director 2/64 Release Notes*.

For the latest information, documentation, and firmware releases, please visit the HP StorageWorks website:

<http://h18006.www1.hp.com/storage/saninfrastructure.html>

For information about Fibre Channel standards, visit the Fibre Channel Industry Association website located at <http://www.fibrechannel.org>.

Conventions

Conventions consist of the following:

- Document conventions
- Text symbols
- Equipment symbols

Document conventions

This document follows the conventions in [Table 1](#).

Table 1: Document conventions

Convention	Element
Blue text: Figure 1	Cross-reference links
Bold	Menu items, buttons, and key, tab, and box names
<i>Italics</i>	Text emphasis and document titles in body text
Monospace font	User input, commands, code, file and directory names, and system responses (output and messages)
<i>Monospace, italic font</i>	Command-line and code variables
Blue underlined sans serif font text (http://www.hp.com)	Web site addresses

Text symbols

The following symbols may be found in the text of this guide. They have the following meanings:



WARNING: Text set off in this manner indicates that failure to follow directions in the warning could result in bodily harm or death.



Caution: Text set off in this manner indicates that failure to follow directions could result in damage to equipment or data.

Tip: Text in a tip provides additional help to readers by providing nonessential or optional techniques, procedures, or shortcuts.

Note: Text set off in this manner presents commentary, sidelights, or interesting points of information.

Equipment symbols

The following equipment symbols may be found on hardware for which this guide pertains. They have the following meanings:



Any enclosed surface or area of the equipment marked with these symbols indicates the presence of electrical shock hazards. Enclosed area contains no operator serviceable parts.

WARNING: To reduce the risk of personal injury from electrical shock hazards, do not open this enclosure.




Any RJ-45 receptacle marked with these symbols indicates a network interface connection.

WARNING: To reduce the risk of electrical shock, fire, or damage to the equipment, do not plug telephone or telecommunications connectors into this receptacle.



Any surface or area of the equipment marked with these symbols indicates the presence of a hot surface or hot component. Contact with this surface could result in injury.

WARNING: To reduce the risk of personal injury from a hot component, allow the surface to cool before touching.



Power supplies or systems marked with these symbols indicate the presence of multiple sources of power.

WARNING: To reduce the risk of personal injury from electrical shock, remove all power cords to completely disconnect power from the power supplies and systems.



Any product or assembly marked with these symbols indicates that the component exceeds the recommended weight for one individual to handle safely.

WARNING: To reduce the risk of personal injury or damage to the equipment, observe local occupational health and safety requirements and guidelines for manually handling material.

Rack stability

Rack stability protects personnel and equipment.



WARNING: To reduce the risk of personal injury or damage to the equipment, be sure that:

- The leveling jacks are extended to the floor.
 - The full weight of the rack rests on the leveling jacks.
 - In single rack installations, the stabilizing feet are attached to the rack.
 - In multiple rack installations, the racks are coupled.
 - Only one rack component is extended at any time. A rack may become unstable if more than one rack component is extended for any reason.
-

Getting help

If you still have a question after reading this guide, contact an HP authorized service provider or access our web site: <http://www.hp.com>.

HP technical support

Telephone numbers for worldwide technical support are listed on the following HP web site: <http://www.hp.com/support/>. From this web site, select the country of origin.

Note: For continuous quality improvement, calls may be recorded or monitored.

Be sure to have the following information available before calling:

- Technical support registration number (if applicable)
- Product serial numbers
- Product model names and numbers
- Applicable error messages
- Operating system type and revision level
- Detailed, specific questions

HP storage web site

The HP web site has the latest information on this product, as well as the latest drivers. Access storage at: <http://www.hp.com/country/us/eng/prodserv/storage.html>. From this web site, select the appropriate product or solution.

HP authorized reseller

For the name of your nearest HP authorized reseller:

- In the United States, call 1-800-345-1518
- In Canada, call 1-800-263-5868
- Elsewhere, see the HP web site for locations and telephone numbers: <http://www.hp.com>.

Overview



This chapter contains the following HP StorageWorks Director 2/64 information:

- [Director Description](#), page 18
- [Features](#), page 18
- [Hardware Components](#), page 24
- [Tools and Test Equipment](#), page 31
- [Optional Kits](#), page 34

Director Description

The director is a second-generation, 64-port product that provides dynamic switched connections between Fibre Channel servers and devices in a SAN environment. Directors are managed and controlled through an High Availability Fabric Manager (HAFM) appliance with HAFM and Director 2/64 Element Manager installed. The HAFM appliance is a 1U rack-mount appliance that provides a central point of control for up to 48 directors and/or edge switches.

Multiple directors and the HAFM appliance communicate through the customer's local area network (LAN).

Features

Features of the Director 2/64 include:

- Scalable from 32 to 64 User ports (with optional UPM 2 Gb add-on)
- 100% dynamic non-blocking, cut through switching with congestion queuing
- Online error detection, error isolation, and error recovery
- Redundant, hot-pluggable components
- Full duplex 200 MB/sec per port performance
- Less than 2-μs average switch latency
- 100-km distance support (60 buffers), with use of repeaters
- Small form factor, hot-pluggable optical transceivers, auto configure G_ports
- Combination short-wave or long-wave laser transceivers
- Redundant power supplies and fan modules
- Online product repair for Field Replaceable Units (FRUs)
- Periodic health check and enhanced system monitoring
- Non-disruptive firmware load and update

Director Management

The director is managed and controlled through:

- The *HAFM* application. This graphical user interface (GUI) resides on the HAFM appliance and provides a single point of management for all directors, and a launching point for the Director 2/64 Element Manager.
- Simple network management protocol (SNMP). A SNMP agent is implemented through the *HAFM* application that allows administrators on SNMP management workstations to access director management information using any standard network management tool. Administrators can assign internet protocol (IP) addresses and corresponding community names for up to 12 SNMP workstations functioning as SNMP trap message recipients. Refer to the *HP StorageWorks SNMP Reference Guide for Directors and Edge Switches* for more information.
- The Internet using the Embedded Web Server (EWS) interface installed on the director. This interface supports configuration, statistics monitoring, and basic operation of the director, but does not offer all the capabilities of the Director 2/64 Element Manager. Administrators launch the EWS interface from a remote PC by entering the director's IP address as the internet URL, then entering a user name and password at a login screen. The PC browser then becomes a management console.

Note: The default user name for the right to view status and other information is "operator." The default user name for the right to modify configuration data, perform maintenance tasks, or perform other options is "Administrator." The default password for both user names is "password."

- The command line interface (CLI). The CLI allows you to access many HAFM and Element Manager functions while entering commands during a telnet session with the director. The primary purpose of the CLI is to automate management of a large number of directors using scripts. The CLI is not an interactive interface; no checking is done for pre-existing conditions and no prompts display to guide users through tasks. Refer to the *HP StorageWorks CLI Reference Guide for Directors and Edge Switches* for more information.
- A customer-supplied PC or UNIX-based platform with the HAFM appliance and client HAFM and Director Element Manager installed.
- A customer-supplied remote workstation communicating with the HAFM appliance through a corporate intranet.

- A customer-supplied PC platform with a network connection to the EWS interface installed on the director.
- A customer-supplied server platform communicating with the switch through a LAN or corporate intranet. The *HAFM* applications are ordered and installed on the server by the customer.

Error-Detection, Reporting, and Serviceability

The director provides the following error-detection, reporting, and serviceability features:

- Light-emitting diodes (LEDs) on director FRUs and the front bezel that provide visual indicators of hardware status or malfunctions.
- System and threshold alerts, event logs, audit logs, link incident logs, threshold alert logs, and hardware logs that display director, Ethernet link, and Fibre Channel link status at the HAFM appliance, remote workstation, or EWS.
- Diagnostic software that performs power-on self-tests (POSTs) and port diagnostics (internal loopback, external loopback, and Fibre Channel (FC) wrap tests). The FC wrap test applies only when the director is configured to operate in FICON management style.
- An internal modem for use by support personnel to dial in to the HAFM appliance for event notification and to perform remote diagnostics.
- Automatic notification of significant system events (to support personnel or administrators) through e-mail messages or the call-home feature at the HAFM appliance.

Note: The call-home feature is not available through the EWS interface.

- An RS-232 maintenance port at the rear of the director (port access is password-protected) that enables installation or service personnel to change the director's internet protocol (IP) address, subnet mask, and gateway address.
- Redundant FRUs—logic cards, power supplies, and cooling fans—that are removed or replaced without disrupting director or Fibre Channel link operation.

- A modular design that enables quick removal and replacement of FRUs without tools or equipment.
- Concurrent port maintenance—UPM cards are added or replaced and fiber-optic cables are attached to ports without interrupting other ports or director operation.
- Beaconsing to assist service personnel in locating a specific port, FRU, or director in a multi-switch environment. When port beaconsing is enabled, the amber LED associated with the port flashes. When FRU beaconsing is enabled, the amber (service required) LED on the FRU flashes. When unit beaconsing is enabled, the system error indicator on the front bezel flashes. Beaconsing does not affect port, FRU, or director operation.
- Data collection through the Element Manager on the HAFM appliance to help isolate system problems. The data includes a memory dump file and audit, hardware, and engineering logs.
- Status monitoring of redundant FRUs and alternate Fibre Channel data paths to ensure continued director availability in case of failover. The *HAFM* application queries the status of each backup FRU daily. A backup FRU failure is indicated by an illuminated amber LED.
- SNMP management using the Fibre Alliance management information base (MIB) Version 3.1, that runs on the HAFM appliance. Up to 12 authorized management workstations can be configured through the *HAFM* application to receive unsolicited SNMP trap messages. The trap messages indicate operational state changes and failure conditions.
- SNMP management using the Fibre Channel Fabric Element MIB (Version 1.1), transmission control protocol/internet protocol (TCP/IP) MIB-II definition (RFC 1213), or a product-specific MIB that runs on each director. Up to six authorized management workstations can be configured through the Element Manager on the HAFM appliance to receive unsolicited SNMP trap messages. The trap messages indicate operational state changes and failure conditions.

Note: For more information about SNMP support provided by HP products, refer to the *HP StorageWorks SNMP Reference Guide for Directors and Edge Switches*.

Zoning

The director supports a name server zoning feature that partitions attached devices into restricted-access groups called zones. Devices in the same zone can recognize and communicate with each other through switched port-to-port connections. Devices in separate zones cannot communicate with each other.

Zoning is configured by authorizing or restricting access to name server information associated with device N_Ports that attach to director fabric ports (F_Ports). A zone member is specified by the port number to which a device is attached, or by the eight-byte (16-digit) World Wide Name (WWN) assigned to the host bus adapter (HBA) or Fibre Channel interface installed in a device. A device can belong to multiple zones.



Caution: If zoning is implemented by port number, a change to the director fiber-optic cable configuration disrupts zone operation and may incorrectly include or exclude a device from a zone.

If zoning is implemented by WWN, removal and replacement of a device HBA or Fibre Channel interface (thereby changing the device WWN) disrupts zone operation and may incorrectly include or exclude a device from a zone.

In Open Fabric mode, only zoning by WWN is supported. Zoning by port numbers is not supported.

Zones are grouped into zone sets. A zone set is a group of zones that is enabled (activated) or disabled across all directors and edge switches in a multi-switch fabric. Only one zone set can be enabled at one time.

Multi-Switch Fabrics

A Fibre Channel topology that consists of one or more interconnected directors or switch elements is called a fabric. Operational software provides the ability to interconnect directors (through expansion port (E_Port) connections) to form a multi-switch fabric. The data transmission path through the fabric is typically determined by fabric elements and is user-transparent. Subject to zoning restrictions, devices attached to any interconnected director can communicate with each other through the fabric.

Because a multi-switch fabric is typically complex, maintenance personnel should be aware that several factors can degrade fabric performance or cause connectivity failures. These factors include:

- **Domain ID assignment**—Each director in a fabric is identified by a unique domain ID that ranges from 1 through 31. A domain ID of 0 is invalid. If two operational fabrics join, they determine if any domain ID conflicts exist between the fabrics. If one or more conflicts exist, the E_Ports that form the interswitch link (ISL) segment to prevent the fabrics from joining.
- **Zoning**—In a multi-switch fabric is configured on a fabric-wide basis, and a change to the zoning configuration is applied to all directors and switch elements in the fabric. To ensure zoning is consistent across a fabric, the following rules are enforced when two fabrics (zoned or unzoned) join:
 - **Fabric A unzoned and Fabric B unzoned**—The fabrics join successfully, and the resulting fabric remains unzoned.
 - **Fabric A zoned and Fabric B unzoned**—The fabrics join successfully, and fabric B automatically inherits the zoning configuration from fabric A.
 - **Fabric A unzoned and Fabric B zoned**—The fabrics join successfully, and fabric A automatically inherits the zoning configuration from fabric B.
 - **Fabric A zoned and Fabric B zoned**—The fabrics join successfully only if the zone configurations can be merged. If the fabrics cannot join, the connecting E_Ports segment and the fabrics remain independent.

Zone configurations for two fabrics are compatible (the zones can join) if the active zone set name is identical for each fabric, and if zones with the same name have identical elements.

- **Port segmentation**—When an ISL activates, directors exchange operating parameters to determine if they are compatible and can join to form a single fabric. If they are incompatible, the connecting E_Port at each director segments to prevent the creation of a single fabric. A segmented link transmits only Class F traffic; the link does not transmit Class 2 or Class 3 traffic. The following conditions cause ports to segment:
 - **Incompatible operating parameters**—Either the resource allocation timeout value (R_A_TOV) or error detect timeout value (E_D_TOV) is inconsistent between directors. To prevent E_Port segmentation, the same E_D_TOV and R_A_TOV must be specified for each director.
 - **Duplicate domain IDs**—One or more domain ID conflicts are detected.
 - **Incompatible zoning configurations**—Zoning configurations for the directors are not compatible.


- **Build fabric protocol error**—A protocol error is detected during the process of forming the fabric.
- **No principal switch**—No director in the fabric is capable of becoming the principal switch.
- **No response from attached switch**—After a fabric is created, each director in the fabric periodically verifies operation of all attached switches and directors. An ISL segments if a switch or director does not respond to a verification request.
- **ELP retransmission failure timeout**—A director that exhibits a hardware failure or connectivity problem cannot transmit or receive Class F frames. The director did not receive a response to multiple exchange link protocol (ELP) frames, did not receive a fabric login (FLOGI) frame, and cannot join an operational fabric.

Hardware Components

The Director provides a modular design that enables quick removal and replacement of FRUs. The following sections define Director 2/64 main components.

Front View

[Figure 1](#) shows Director 2/64 components accessible from the front of the Director. Component descriptions follow the figure.



SHR-2272

- | | |
|-------------------------------|--|
| ❶ Power and system error LEDs | ❹ Cable management assembly ¹ |
| ❷ UPM cards | ❺ Front bezel |
| ❸ Power supplies | ❻ CTP2 cards |

1. Provided in rack-mount kits HP 9000, HP 10000, and HP 11000 Series only.

Figure 1: Director components—front

CTP2 Card

The Director 2/64 ships with two Control Processor (CTP2) cards. The active CTP2 card initializes and configures the director after power on, and contains the microprocessor and associated logic that coordinate director operation. The second CTP2 card serves as a backup. A CTP2 card provides an Initial Machine Load (IML) button on the faceplate. When the button is pressed and held for three seconds, the director reloads firmware and resets the CTP2 card without switching off power or affecting operational fiber-optic links.

Each CTP2 card also provides a 10/100 megabit per second (Mbps) RJ-45 twisted pair connector on the faceplate that attaches to an Ethernet Local Area Network (LAN).

Each CTP2 card provides System Services Processor (SSP) and Embedded Port (EP) subsystems. The SSP subsystem runs director applications, communicates with director ports, and controls the RS-232 maintenance port and 10/100 Mbps ethernet port. The EP subsystem provides Class F processing, and manages frame transmission to and from the Serial Crossbar Assembly (SBAR). In addition, CTP2 cards provide non-volatile memory for storing firmware director configuration information, persistent operating parameters, and memory dump files. Director firmware is upgraded concurrently (without disrupting operation).

Each card faceplate contains a green light emitting diode (LED) that turns ON if the card is operational and active, and an amber LED that turns ON if the card fails. The LEDs are OFF on the backup CTP2. The amber LED FLASHES if beaconing is enabled.

Front Bezel

The bezel at the front of the Director includes two indicator LEDs. The green power LED turns ON when the director is powered on and operational. If the LED turns OFF, a facility power source, alternating current (AC) power cord, or director power distribution failure is indicated.

The amber system error LED turns ON when the director detects an event requiring immediate operator attention, such as an FRU failure. The LED remains illuminated as long as an event is active. The LED FLASHES if unit beaconing is enabled.

Cable Management Assembly

The cable management assembly positioned at the front of the director provides routing for Ethernet cables attached to CTP2 cards and fiber-optic cables attached to director ports. The assembly rotates up to provide front access to the redundant power supplies.

The cable management assembly is supplied with rack-mount kits for the HP 9000, HP 10000, and HP 11000 Series racks only

Power Supplies

The Director 2/64 uses redundant, load-sharing power supplies which step down and rectify facility input power to provide 48-VDC power to Director FRUs. The power supplies also provide over-voltage and over-current protection. Either power supply can be replaced while the switch is powered on and operational. Each power supply has a separate backplane connection to allow for different AC power sources.

The power supplies are input rated at 85 to 264 VAC. The faceplate of each power supply provides the following status LEDs:

- A green **PWR OK** LED turns ON if the power supply is operational and receiving AC power.
- An amber **FAULT** LED turns ON if the power supply fails.
- An amber **TEMP** LED turns ON if the power supply shuts down due to an over temperature condition.
- An amber **I LIM** LED turns ON if the power supply is overloaded and operating at the current limit (15.6 A).

Power supply requirements are listed in [Appendix B](#).

UPM Card

Each Universal Port Module (UPM) card provides four full-duplex generic ports (G_Ports) that transmit or receive data at 1.063 or 2.125 gigabits per second (Gbps). G_Port functionality depends on the type of cable attachment. UPM cards use Non-Open Fiber Control (NOFC) Class 1 laser transceivers that comply with Section 21 of the Code of Federal Regulations (CFR), Subpart J as of the date of manufacture.

Depending on device connections, G_Ports work as follows:

- If the G_Port is attached to a Fibre Channel device, the port functions as a fabric port (F_Port). An F_Port is the interface on a director that connects to a device N_Port.
- If the G_Port is attached to another director to form an Interswitch Link (ISL), the port functions as an expansion port (E_Port). A multi-switch fabric is formed through multiple directors and ISLs.

[Figure 2](#) shows the faceplate of an UPM.




Figure 2: UPM card LEDs and connectors

Single-mode or multi-mode fiber-optic cables attach to UPM cards through small form factor pluggable (SFP) optic transceivers. The fiber-optic transceivers provide duplex connectors, and can be detached from UPM cards (through a 10-pin interface) for easy replacement. Three fiber-optic transceiver types are available:

- **Short-wave Laser**—Short-wave laser transceivers provide connections for transferring data over short distances (2 to 500 meters) through 50- μm (500 meters) or 62.5- μm (200 meters) multi-mode fiber.


Note: Hewlett-Packard recommends 50- μm fiber-optic cable for any new installation requiring multi-mode fiber.

- **Long-wave Laser**—Long-wave laser transceivers provide connections for transferring data over long distances (up to 10 kilometers) through 9- μm single-mode fiber.

- **Extended reach long-wave Laser**—Long-wave laser transceivers that provide connections for transferring data over extended long distances (up to 35 kilometers) through 9- μ m single-mode fiber.

Rear View

Figure 3 shows the components accessible from the rear of the Director2/64.



SHR-2309

- ❶ Power module assembly ❸ Fan modules
❷ SBAR assemblies

Figure 3: Director components—rear

Fan Modules

Two fan modules, each containing three fans (six fans total), provide cooling for director FRUs, as well as providing redundancy for continued operation if a fan fails.

The fan module can be replaced while the director is powered on and operating, provided the module is replaced within 10 minutes (after which software powers off the director). An amber LED for each fan module turns ON if one or more fans fail or rotate at insufficient velocity.

SBAR Assembly

The director ships with two SBAR assemblies. The active SBAR is responsible for Fibre Channel frame transmission from any director port to any other director port. Connections are established without software intervention. The assembly accepts a connection request from a port, determines if a connection can be established, and establishes the connection if the destination port is available. The assembly also stores busy, source connection, and error status for each director port.

The backup SBAR takes over operation if the active assembly fails, and provides the ability to maintain connectivity and data frame transmission without interruption. The transition to the backup assembly is transparent to attached devices.

Each SBAR assembly consists of a card and steel carriage that mounts flush on the backplane. The carriage provides protection for the back of the card, distributes cooling airflow, and assists in aligning the assembly during installation. The rear of the carriage contains a green LED that turns ON if the assembly is operational and active, and an amber LED that turns ON if the assembly fails. The amber LED FLASHES if FRU beaconing is enabled.

Power Module Assembly

The power module assembly is located at the bottom rear of the director. The module provides the following.

- Two single-phase AC power connectors. Each connector is input rated at 85 to 264 VAC.
- A power switch (circuit breaker) that controls AC power distribution to both power supplies. The breaker is set manually, or is automatically tripped by internal software if thermal sensors indicate the director has overheated.
- A 9-pin maintenance port that provides a connection for a local terminal or dial-in connection for a remote terminal.

Tools and Test Equipment

This section describes tools and test equipment that may be required to test, service, and verify operation of the director and attached HAFM appliance. These tools are either supplied with the director or must be supplied by service personnel.

Tools Supplied with the Director

The following tools are supplied with the director. Use of the tools may be required to perform test, installation, service, or verification tasks.

- **Torque tool with hexagonal adapter**—The torque tool with 5/32" hexagonal adapter, as shown in [Figure 4](#), is required to remove and replace director logic cards.



Caution: The torque tool supplied with the Director 2/64 is designed to tighten director logic cards and is set to release at a torque value of six inch-pounds. Do not use an Allen wrench or torque tool designed for use with another HP product. Use of the wrong tool may overtighten and damage logic cards.




Figure 4: Torque tool and hex adapter

- **Loopback plug**—An SFP multi-mode (shortwave laser) or single-mode (longwave laser) loopback plug, as shown in [Figure 5](#), is required to perform port loopback diagnostic tests. One loopback plug is shipped with the director, depending on the type of port transceivers installed. Both plugs are shipped if shortwave laser and longwave laser transceivers are installed.




Figure 5: Loopback plug

- **Fiber-optic protective plug**—For safety and port transceiver protection, fiber-optic protective plugs, as shown in [Figure 6](#), must be inserted in all director ports without fiber-optic cables attached. The director is shipped with protective plugs installed in all ports.




Figure 6: Fiber-Optic protective plug

- **Null modem cable**—An asynchronous RS-232 null modem cable, as shown in [Figure 7](#), is required to configure director network addresses and acquire event log information through the maintenance port. The cable has nine conductors and DB-9 male and female connectors.




Figure 7: Null modem cable

Tools Supplied by Service Personnel

The following tools are expected to be supplied by service personnel performing director installation or maintenance actions. Use of the tools may be required to perform one or more test, service, or verification tasks.

- **Scissors or pocket knife**—A sharp cutting edge (scissors or knife blade) may be required to cut the protective strapping when unpacking replacement FRUs.
- **Standard flat-tip and cross-tip (Phillips) screwdrivers**—Screwdrivers are required to remove, replace, adjust or tighten various FRUs, chassis, or cabinet components.
- **T10 Torx® tool**—The tool is required to rack-mount the director or to remove, replace, adjust, or tighten various chassis or cabinet components.
- **Electrostatic discharge (ESD) grounding cable with attached wrist strap**—Use of the ESD wrist strap is required when working in and around the director card cage.
- **Maintenance terminal (desktop or notebook PC)**—The PC is required to configure director network addresses and acquire event log information through the maintenance port. The PC must have:
 - The Microsoft® Windows 98®, Windows 2000®, Windows 2003®, Windows XP®, or Windows ME® operating system installed.
 - RS-232 serial communication software (such as ProComm Plus™ or HyperTerminal™) installed. HyperTerminal is provided with Windows operating systems.

- **Fiber-optic cleaning kit**—The kit contains tools and instructions to clean fiber-optic cable, connectors, loopback plugs, and protective plugs.

Optional Kits

Contact your Hewlett-Packard authorized service provider to purchase the following optional Director kits. See [Table 2](#) for descriptions of Director 2/64 optional kits.

Table 2: Director Optional Kits

Supporting Kit	Description
HP Full Volatility License. Part Number: A7498A	Provides a license to use Full Volatility feature.
HP Open Trunking License. Part Number: A7505A	Provides a license to use Open Trunking feature.
HP SANtegrity Binding License. Part Number: 317073-B21	Provides a license to use SANtegrity Binding feature.
300m Optical Transceiver Kit, Part Number: 300834-B21	Provides short-wave optical transceiver for the Director.
10km Long Distance Optical Transceiver Kit, Part Number: 300835-B21	Provides 10km long-wave optical transceiver for the Director.
35km Extended Reach Optical Transceiver Kit, Part Number: 300836-B21	Provides 35km long-wave optical transceiver for the Director.
HP 9000, HP 10000, and HP 11000 Rack-Mount Kit, Part Number: 302659-B21	Provides rack-mounting hardware.
HP system/e and industry-standard 19-in rack Mount Kit, Part Number: 339227-B21	Provides rack-mounting hardware.
2Gb UPM Port Module Kit, Part Number: 316094-B21	Provides 4 additional short-wave ports for the Director 2/64.

Installing and Configuring the Director

2

This chapter describes tasks to install, configure, and verify operation of the Director. This chapter describes the following:

- [Installation Options](#), page 36
- [Review Installation Requirements](#), page 37
- [Unpack and Inspect the Director](#), page 40
- [Install the Director in a Rack](#), page 46
- [Configure Director Network Information](#), page 70
- [LAN-Connect the Director](#), page 77
- [HAFM Appliance](#), page 78
- [Frequently Used HAFM Settings](#), page 84
- [Connecting Cables to the Fibre Channel Ports](#), page 109
- [Connecting the Director to a Fabric](#), page 110
- [Unpacking, Inspecting, and Installing the Ethernet Hub \(Optional\)](#), page 111
- [Using HAFM from a Remote Location](#), page 112

Installation Options

The director is installed in one of two configurations. The options are:

- **Table or desk top**—One or more directors and an optional HAFM appliance are delivered and installed at the customer facility on a desk or table top. Ethernet cabling distance and local area network (LAN) addressing issues must be considered.
- **Customer-supplied equipment rack**—One or more directors and an optional HAFM appliance are delivered to the customer facility for installation in an HP or customer-supplied equipment rack. Rack-mount hardware is provided in the shipping container. Ethernet cabling, distance, and LAN addressing issues must be considered.

Review Installation Requirements

The director is delivered stand-alone and ready to be mounted in an HP 9000, HP 10000, HP 11000, HP system/e, or industry-standard 19-in rack. Ethernet cabling, distance, and LAN addressing issues must be considered.

Review the following checklist before installing the switch:

- Prepare a site plan. Consult the *HP StorageWorks SAN High Availability Planning Guide*.
- Manage the director using one of the following methods:
 - A browser-capable PC and LAN segment connectivity to the HAFM appliance to support director management through HAFM and the Element Manager.
 - A browser-capable PC and Internet connectivity to support director management through the EWS interface.
- Verify that required technical personnel are available and scheduled for the installation.
- Obtain the required fiber-optic cables (multi-mode or single-mode). Verify cable length and required connectors.
- Obtain a Hewlett-Packard 19-inch equipment rack.
- Verify that the front panel air temperature does not exceed 40 °C (104 °F) during operation.
- Verify that there is space in the rack. The director is 9U (15.75 in) high. In addition, 1U is required in the HP system/e and industry-standard 19-in racks for the rail tray kit. Note that the tray provides 1U of space for cable management.
- Verify that the rack is stable.
- If applicable, obtain the necessary remote workstations or Simple Network Management Protocol (SNMP) workstations. Workstations are customer-supplied and connected through a corporate or dedicated LAN.
- Verify that all other equipment installed in the rack is connected to a reliable ground connection; do not rely on connections to a branch circuit, such as a power strip.
- HP recommends securing the rack mechanically to prevent it from tipping over during a natural disaster, such as an earthquake.

Items Required for Installation

Locate the following items before beginning the installation procedure:

- Lift device (recommended).
- Director 2/64.
- An HP 9000, HP 10000, HP 11000, HP system/e, or industry-standard 19-in rack, or any rack with the following specifications:
 - A minimum depth of 24.5 in.
 - 19 in wide.
 - A minimum opening size of 10U available (9U for the director and 1U for the rail tray kit).
- Two power outlets or different branches (for redundancy).
- Torque driver with cross-tip bit (for setting 22 in/lb. of torque).
- Fiber-optic protective plug—For safety and port transceiver protection, fiber-optic protective plugs must be inserted in all director ports without fiber-optic cables attached. The director is shipped with protective plugs installed in all ports.
- Null modem cable—An asynchronous RS-232 null modem cable is required to configure director network addresses and obtain event log information through the maintenance port. The cable has nine conductors and two DB-9 female connectors. A null modem cable specially designed for this application is supplied with the Director 2/64.
- Standard flat-tip and cross-tip Phillips screwdrivers—Required to remove, replace, adjust or tighten various FRUs, chassis, or rack components.
- Electrostatic discharge (ESD) grounding cable with attached wrist strap—Required when working in and around the director card cage.
- Maintenance terminal (desktop or notebook computer)—Required to configure director network addresses and acquire event log information through the maintenance port. Computer requirements include:
 - Microsoft Windows 98, Windows Millennium Edition, Windows NT 4.0, Windows 2000, or Windows XP operating system installed.
 - RS-232 serial communication software (for example, ProComm Plus or HyperTerminal).

Note: The HAFM appliance may be used for the maintenance terminal function. The *HyperTerminal* application is included with the Windows 2000 operating system provided with the HAFM appliance.

Select an Operating Location

Install the director in a secure or limited-access area to ensure that cable connections are not compromised. Also, make sure to install the director in an area with the necessary ventilation and power requirements.

Cooling and Power Requirements

Two fan modules, each containing three fans (six fans total), provide cooling and redundancy fans for the director. The air intake for the director must satisfy an operating environment temperature requirement of 40°F to 104°F (4°C to 40°C).

Director power requirements:

- Input voltage: 100 to 120 or 200 to 240 VAC
- Input frequency: 50/60 Hz



Caution: Do not block Director 2/64 air vents. The switch uses ambient air for cooling.

Unpack and Inspect the Director

Unpack and inspect the director as follows:

1. Inspect the shipping container for damage caused during transit.
2. Unpack the shipping cartons.



WARNING: The Director weighs approximately 115 pounds. Use proper handling and lifting equipment to reduce the possibility of injury or product damage.

3. Verify carton contents, as shown in [Figure 8](#) and [Table 3](#) for the Director 2/64, as shown in [Figure 9](#) and [Table 4](#) for the HP 9000, HP 10000, and HP 11000 Series Rack kit, and as shown in [Figure 10](#) and [Table 5](#) for the HP system/e and industry-standard 19-in rack.

Note: If any items are damaged or missing, please contact a Hewlett-Packard authorized service provider or reseller.





Figure 8: Carton contents for a Director 2/64

Table 3: Shipping Carton Contents for a Director 2/64

Number	Item
❶	One HP StorageWorks Director Product CD containing firmware, license, documentation
❷	<i>HP StorageWorks Director 2/64 Installation Guide</i>

Table 3: Shipping Carton Contents for a Director 2/64 (Continued)

Number	Item
③	Two Power Distribution Unit (PDU) power cords
④	Two standard AC power cords
⑤	Four multi-mode, short-wave loopback plugs
⑥	One torque driver with integrated 5/32" bit
⑦	One 10-foot null modem cable
⑧	HP StorageWorks Director

**Figure 9: Carton contents for an HP 9000, HP 10000, and HP 11000 Series Rack****Table 4: Shipping Carton Contents for an HP 9000, HP 10000, and HP 11000 Series Rack**

Number	Item
①	HP 9000, HP 10000, and HP 11000 Series Rack-Mounting Kit containing: <ul style="list-style-type: none"> ■ Two front mounting brackets ■ Two rear mounting plates ■ Two rear angle brackets
②	Two shelf brackets

Table 4: Shipping Carton Contents for an HP 9000, HP 10000, and HP 11000 Series Rack (Continued)

Number	Item
③	Pouch containing HP 9000, HP 10000, and HP 11000 Series rack-mounting hardware: <ul style="list-style-type: none"> ■ Eight 10-32 x 0.375 in Phillips panhead screws—Installs two shelf brackets to rails ■ Six 10-32 x 0.375 in Phillips panhead screws—Installs two front mounting brackets to rails ■ Four 10-32 X 0.25 in Phillips countersunk screws—Installs front brackets to switch ■ Ten 10-32 cage nuts—Secures front and rear shelf brackets. ■ Four 0-32 x 0.375 in Phillips panhead screws—Installs rear bracket sections ■ Four 10-32 X 0.25 in Phillips countersunk screws—Installs rear mounting plates to chassis ■ Four 10-32 X 0.375 in Phillips panhead screws—Installs two rear angle brackets ■ Eight square alignment washers
④	One cable management assembly




Figure 10: Carton contents for a HP system/e or industry-standard 19-in rack installation

Table 5: Parts for Installing in an HP System/e and Industry-Standard 19-inch Rack

Label	Item
❶	HP StorageWorks Director (part number: A6534-62001)
❷	Rail Tray Kit (part number: A6534-60016): <ul style="list-style-type: none"> ■ One rail tray ■ Two mounting brackets ■ Two M3 Tinnerman nuts ■ Four Torx T25 16 mm M5 SEM screws
❷, ❸, ❺	Mounting hardware: <ul style="list-style-type: none"> ■ Rack-mount brackets (part number: A6534-60014) containing: ■ Two front mounting brackets (❺) ■ Two rear mounting plates (❷) ■ Two rear angle brackets (❸) ■ Switch rack hardware (part number: A6534-62002): ■ Twenty-two Torx T25 16 mm M5 SEM screws (includes extras) ■ Eighteen sheet metal nuts ■ Eight 10-32 Phillips flat-head screws (includes extras)

Install the Director in a Rack

The following sections provide instructions for installing the Director in either the HP 9000, HP 10000, and HP 11000 Series Rack or in the HP system/e and industry-standard 19-in racks.

Required Tools

Obtain the following tools:

- For a HP system/e and industry-standard 19-in rack:
 - #2 Phillips screwdriver
 - Torque screwdriver
- For an HP 9000, HP 10000, and HP 11000 Series Rack:
 - #2 Phillips screwdriver
 - Torx head driver T25

Tips for Installing More than One Switch

Review the following tips:

- Install the first director in the lowest position of the rack, allocated for switches.
- If installing more than one switch, Hewlett-Packard recommends installing an optional PDU in the bottom of the rack. Hewlett-Packard ships two PDU power cords with the Director.
- Install additional switches in position directly above one another.
- Make sure to connect power cables as you install each individual switch.

Transfer the Director to the Lift Device

Use these steps to position the Director next to the rack.



WARNING: The Director weighs approximately 115 pounds. Use proper handling and lifting equipment to reduce the possibility of injury or product damage.

Two people will need to work together to transfer the director to the lift. Make sure the wheels of the lift cannot roll as you transfer the director to the lift. Move the director slowly and carefully onto the lift to prevent back and hand injury. Dropping the director could injure personnel or damage the equipment.

1. Position the lift device next to the director.
2. Using a pallet jack, raise the pallet on which the director is mounted to the same height as the top surface of the lift device.
3. Slide the director across from the pallet to the lift device.
4. Determine the appropriate rack-mount position. Remember that the director is 9U (15.75 inches) high.

HP 9000, HP 10000, and HP 11000 Series Rack Installation

To install the director in an HP 9000, HP 10000, or HP 11000 Series Rack, complete the procedures in the following sections:

- [Install the Shelf Brackets in a HP 9000, HP 10000, and HP 11000 Series Rack](#), page 47
- [Prepare the Switch for Installation](#), page 48
- [Finalize the Rack-Mounting Procedure](#), page 51

Install the Shelf Brackets in a HP 9000, HP 10000, and HP 11000 Series Rack

Use these steps to install the two shelf brackets in the rack.

Note: Consider leaving the bottom and top U positions open to permit easy accessibility to the cables entering and exiting the rack.


1. Determine the appropriate placement for the switch inside the rack. It is important to consider the number of switches you intend to install. See [“Tips for Installing More than One Switch”](#) on page 46.

2. Locate the small, round marker hole on the rails that coincides with the location selected in [step 1](#). Each marker hole delineates the beginning of one rail unit, or U.
3. Locate the square opening in the rail that corresponds with the appropriate marker hole, as shown in [Figure 11](#).
4. Position the higher, shelf bracket threaded hole in this square opening, as shown in [Figure 11](#).
5. Orient the shelf bracket in the rails.
6. Place the square washer provided on the front of the rail so that the two bumps on the washer sit in opposite corners in the rail's square hole.
7. Insert the panhead Phillips screw, and partially tighten to temporarily stabilize the bracket.
8. Make sure the shelf bracket is level, and align the rear of the shelf bracket with the appropriate position on the rear rail, as shown in [Figure 11](#).
9. Repeat [step 4](#) through [step 7](#) for the rear end of the shelf bracket.
10. Repeat [step 1](#) through [step 9](#) for the second shelf bracket.
11. Completely tighten all screws attaching shelf brackets to the rack's rails.
12. Using a torque driver, torque the screws to 22 in/lb.

Prepare the Switch for Installation

The following section describes how to install the mounting hardware that attaches the switch to the rails. This hardware includes:

- Two front mounting brackets
- Two rear mounting plates
- Ten cage nuts
- Eight screws



SHR-2265B

- ❶ Marker hole
- ❷ Square opening in rail


- ❸ Screws with captive lock and flat washers
- ❹ Square alignment washers

Figure 11: Securing shelf brackets

Secure the Mounting Hardware

Use these steps to secure the mounting hardware to the switch.

1. Locate the two front mounting brackets in the shipping carton.
2. Secure the front mounting brackets on either side of the switch, as shown in [Figure 12](#). For each front mounting bracket, use the two (2) flathead countersunk Phillips screws (10-32 x 0.25 in) provided.



SHR-2264

Figure 12: Securing the two mounting brackets

3. Using a torque driver, torque the screws to 22 in/lb.
4. Locate the two (2) rear mounting plates in the shipping carton.
5. Secure the two (2) rear mounting plates to each side of the switch, as shown in [Figure 12](#). For each plate, use the two (2) flathead countersunk Phillips screws (10-32 x 0.25 in) provided.
6. Using a torque driver, torque the screws to 22 in/lb.

Insert the Cage Nuts

Read the following sections for instructions on inserting front and rear cage nuts in the rack.

Insert the Front Cage Nuts in the Rack

Use these steps to insert the six supplied cage nuts in the rack's front rails:

1. Select one of the front rails.
2. Count up eleven (11) square openings from the top screw of the shelf bracket, and insert the first of three (3) cage nuts.

3. Count up five (5) square openings from the cage nut you just installed, and insert the next cage nut.
4. Count up four (4) square openings and install the third cage nut.
5. Repeat this procedure to install cage nuts in the corresponding front rail.

Insert the Rear Cage Nuts in the Rack

Use these steps to insert the four (4) supplied cage nuts in the rack's rear rails:

1. Select one of the rear rails.
2. Count up six (6) square openings from the top screw of the rear shelf bracket. Insert the first of two (2) cage nuts.
3. Count up sixteen (16) square openings from the cage nut you just installed, and insert the next cage nut.
4. Repeat this procedure to install cage nuts in the corresponding rear rail.

Finalize the Rack-Mounting Procedure

Use the following sections to complete the installation procedure.


After completing the steps outlined in the previous sections, prepare to orient the switch in the rack as follows.



WARNING: The Director weighs approximately 115 pounds. Use proper handling and lifting equipment to reduce the possibility of injury or product damage.

1. Carefully lift the switch into the front of the rack and onto the shelf brackets and slide the switch forward into the rack until the edge of the rear mounting plates are approximately 1 inch from the rack's rails, as shown in [Figure 13](#).
2. Align one rear angle bracket with the cage nuts installed earlier, as shown in "[Insert the Cage Nuts](#)" on page 50.

Note: Make sure that the angle bracket is in contact with the outside surface of the mounting plate.



SHR-2266

Figure 13: Aligning the switch in the rack

3. Loosely attach the rear angle bracket to the rack rail with the two panhead Phillips screws provided, as shown in [Figure 14](#).
4. Repeat [step 2](#) and [step 3](#) for the corresponding rear angle bracket, as shown in [Figure 14](#).
5. The two rear angle brackets now touch the outside surfaces of the rear mounting plates. Slide the switch all the way into the rack to where the front mounting bracket meets the rack rails.
6. If you are certain that the hardware lines up properly, secure the hardware as follows:
 - a. Secure each rear mounting plate to the rear angle bracket with the two screws provided.
 - b. Move to the front of the switch and secure each front mounting bracket with the three screws provided.




Figure 14: Securing the rear angle brackets


7. Using a torque driver, torque the screws to 22 in/lb.
8. Connect the remaining ends of the PDU power cords to separate PDUs (if installed), as shown in [Figure 15](#); otherwise, connect the two standard AC power cords.

Note: Hewlett-Packard recommends installing an optional PDU in the rack. Hewlett-Packard ships two PDU power cords with the Director.



WARNING: Hewlett-Packard power cords are provided for each director power supply. To prevent personal injury by electric shock, use only the supplied power cords. Also, verify that the facility power receptacle is the correct type, supplies the required voltage, and is properly grounded.

9. Connect the equipment rack power cords to separate (for redundancy) facility power sources, providing single-phase, 120 to 240 VAC current.



SHR-2273

Figure 15: AC power connections

HP System/e and Industry-Standard 19-inch Rack Installation

To install the director in a HP system/e or industry-standard 19-in rack, complete the procedures in the following sections:

- [Install the Anti-tip Feet on an HP System/e Rack](#), page 54
- [Install Mounting Bracket Hardware in the Rack](#), page 55
- [Prepare the Front and Rear Rack Columns](#), page 59
- [Prepare the Switch for Installation](#), page 60
- [Finalize the Rack-Mounting Procedure](#), page 61
- [Sliding Shelf Installation—For an HAFM Appliance only](#), page 64
- [Recommended Cable Management](#), page 67

Install the Anti-tip Feet on an HP System/e Rack

Use the following procedure to mount anti-tip feet on a HP system/e rack only, as shown in [Figure 16](#):

1. Place the anti-tip feet (❶), provided in the HP system/e and industry-standard 19-in rack-mount kits on the front and rear of the rack base.
2. Secure the anti-tip feet (❶) to the base of the rack (front and rear).
3. Lower the rack feet (❷) until they touch the floor.




Figure 16: Mounting anti-tip feet for a HP system/e rack

Install Mounting Bracket Hardware in the Rack

Use these steps to install the mounting hardware in a rack.

Note: The 9Us used to mount the switch are called U1 through U9; U1 is the lowest of the 9Us. Note also that 1U below the switch is required for the rail tray for a total of 10U to mount the switch.

1. Determine the appropriate placement for the switch inside the rack. It is important to consider the number of switches you intend to install. See [“Tips for Installing More than One Switch”](#) on page 46.
2. Determine the mounting location for the rail tray, as shown in [Figure 17](#).

Note: The rail tray will be mounted 1U below the switch. Because the switch should be mounted no higher than U11, the tray should be mounted no higher than U10. Make sure there are at least 2Us above the top of the switch empty for the sliding shelf.

3. Locate the rail tray and two rail tray brackets in the shipping carton.




Figure 17: Rail tray mounting location requirement

4. Position and attach both rear brackets, as shown in [Figure 18](#):
 - a. Locate the lowest U of the 9Us chosen for mounting the switch (the lowest being U1).
 - b. Attach each rear rail tray bracket to the rear rack uprights at U1 (one on the left and one on the right).
 - c. Secure each rail tray bracket using one M5 Torx screw.




Figure 18: Attaching a rear rail tray bracket

5. Install a Tinnerman nut in the top holes of U1 for both the left and right rack-front uprights, as shown in [Figure 19](#).




Figure 19: Installing a Tinnerman nut on the rack-front rail in U1

6. Position the rail tray, as shown in [Figure 20](#) and insert the tray into the rack from the front.

Note: Make sure the slots in the sides of the rail tray slide over the posts on the rear rail tray brackets, and the posts on the rail tray's front mounting flanges are inserted into the center holes of U1.




Figure 20: Inserting the rail tray in the rack

7. Secure the rail tray:
 - a. Insert an M5 Torx screw through the top holes in both of the rail tray mounting flanges. The screws pass through the holes in the rack uprights and thread into the Tinnerman nuts installed on the rack uprights in [step 5](#).
 - b. Tighten both M5 Torx screws.

Prepare the Front and Rear Rack Columns

Use the following procedure to prepare the rack for installing a switch:

1. Prepare the front rack columns, as shown in [Figure 21](#):
 - a. Standing at the front of the rack, count up from the top of the rail tray (❶) to the 13th, 19th, and 23rd holes on the rack's front face.
 - b. Slide a sheet metal nut (❷) on each of the located holes.

Note: Three sheet metal nuts should be on each front column face (❸).




Figure 21: Preparing the front rack columns

2. Prepare the rear rack columns, as shown in [Figure 22](#):
 - a. Standing at the back of the rack, count up from the top of the rail tray (❶) to 12th and 28th on the rack's back face.
 - b. Slide a sheet metal nut (❷) on each of the located holes.

Note: Two sheet metal nuts should be on each back column face (③).




Figure 22: Preparing the rear rack columns

Prepare the Switch for Installation

The following section describes how to install the mounting hardware that attaches the switch to the rails. This hardware includes:

- Two front mounting brackets
- Two rear mounting plates
- Eight 10-32, flat-head Phillips screws

Use these steps to secure the mounting hardware to the switch, as shown in [Figure 23](#):

1. Locate the two front mounting brackets in the shipping carton.
2. Position the front mounting bracket (⑤) so that the bracket's angled side faces out and is on the upper part of switch side.

3. Attach the bracket with 10-32, flat-head Phillips screws (4) using the two center threaded holes on the front side of the switch.
4. Repeat [step 2](#) and [step 3](#) for the second front mounting bracket.




Figure 23: Installing the rack-mounting brackets on the switch

5. Locate the two rear mounting brackets in the shipping carton.
6. Position a rear mounting bracket (3) so that the bracket's center holes (1) line up with the 1st and 3rd threaded holes on the back portion of the switch side.

Note: The slotted end (2) of the bracket should face toward the back of the switch.

7. Secure the rear mounting bracket to the switch using two 10-32, flat-head Phillips screws.
8. Repeat [step 6](#) and [step 7](#) for the second rear mounting bracket.

Finalize the Rack-Mounting Procedure

Use the following sections to complete the installation procedure.

After completing the steps outlined in the previous sections, install the switch in the rack as follows.



WARNING: The Director weighs approximately 115 pounds. Use proper handling and lifting equipment to reduce the possibility of injury or product damage.

1. Carefully position the switch in the front of the rack and onto the rail tray, and slide the switch back on the rails until the front mounting brackets are against the front rack columns. [Figure 24](#) illustrates using a lifting jack to position the switch.




Figure 24: Positioning the switch in the rack

2. Mount the switch in the rack, as shown in [Figure 25](#):
 - a. On one side at the back of the switch, position an angle bracket (②) so that the threaded holes (①) are against the slots (⑤) of the rear mounting bracket and the angled side face out.
 - b. Insert the screws (⑥) through the rear mounting bracket slots into the threaded nuts of the angle bracket.
 - c. Insert a second set of screws (④) through the angle bracket and the rail column into the sheet metal nuts on the back rail (③).

- d. Repeat [step a](#) through [step c](#) for the other side at the back of the switch.
- e. At the front of the rack, insert the screws through the front mounting brackets into the sheet metal nuts installed in the rail columns in [step 1](#) of “[Prepare the Front and Rear Rack Columns](#)” on page 59.
- f. Tighten all screws.




Figure 25: Securing the switch to the rack

3. Connect the other ends of the PDU power cords to separate PDUs (if installed), as shown in [Figure 26](#); otherwise, connect the two standard AC power cords.

Note: Hewlett-Packard recommends installing an optional PDU in the rack. Hewlett-Packard ships two PDU power cords with the Director.

Figure 26: AC power connections



WARNING: Hewlett-Packard power cords are provided for each director power supply. To prevent personal injury by electric shock, use only the supplied power cords. Also, verify that the facility power receptacle is the correct type, supplies the required voltage, and is properly grounded.

4. Connect the equipment rack power cords to separate (for redundancy) facility power sources, providing single-phase, 120 to 240 VAC current.

Sliding Shelf Installation—For an HAFM Appliance only

This section only applies to a Management Station. Use the following procedure to install sliding shelf brackets, as shown in [Figure 27](#):

1. Select a U slot above the switch. (It is recommended to select the U slot immediately above the switch. However, other U slots above the switch may also be used.)
2. On each rack rear column, locate the hole (❶) that is 2 holes up from the EIA number of the selected U slot (❸).
3. Line up this hole with the threaded hole on the sliding shelf bracket's side.
4. Using a screw (❷), attach bracket (❺) to the rack.
5. Attach another screw (❹) loosely in the hole on the inside face of the mounting bracket (❺).




Figure 27: Installing the sliding shelf brackets

6. Insert the shelf into the rack so that both rail rear slots (1) slide over the loose screws (2) on the inside face of each bracket, as shown in [Figure 28](#).




Figure 28: Positioning the sliding shelf bracket on a rail rear slot

7. Make sure that the sliding shelf and rails are horizontal, as shown in [Figure 29](#) at the rack front.
8. Push each of the rail front tabs (❶) into the corresponding holes on the rack columns (❷).
9. At the back of the rack, tighten the screws that attach the sliding shelf rails to the mounting brackets, as shown in [Figure 28](#) (❷).




Figure 29: Positioning the sliding shelf bracket at the rack front

Recommended Cable Management

Perform the following procedure after installing a switch, as shown in [Figure 30](#):

1. Install two cable restraints (❶) on each side of the rack in positions that will hold the Fibre Channel cables away from the power supply.
2. Form loose bundles of the installed Fibre Channel cables (❷) on each side of the rack.
3. Wrap the cable bundles with the cable restraints (❶) in two positions on each side of the rack to maintain clearance for power supply access (❸).




Figure 30: Recommended cable management

Power-On Self Test

Use the following steps to run a Power-On Self Test (POST):

1. Power on the PDUs (if used).
2. At the bottom rear of the director, set the power switch (circuit breaker) to the Up position.

The director powers on. The following occurs during POST:

- Amber LEDs on both CTP2 cards and all universal port module (UPM) cards illuminate momentarily.
- The green LED on each CTP2 card (active and backup) turns ON as the card is tested and UPM cards are tested.
- Green LEDs associated with Fibre Channel ports sequentially illuminate as the ports are tested.

3. After successful POST completion, the green power LED on the front bezel, green LED on the active CTP2 card, and green PWR OK LEDs on both power supplies remain ON.
4. If a POST error or other malfunction occurs, refer to the *HP StorageWorks Director 2/64 Service Manual*.

Configure Director Network Information

Use the following sections to configure the director's network addressing scheme.

Default Settings

The director is delivered with the following default network addresses:

- **MAC address**—The Media Access Control (MAC) address is programmed into FLASH memory on the CTP2 card at the time of manufacture. The address is in xx.xx.xx.xx.xx.xx format, where xx is a hexadecimal pair.
- **IP address**—The factory preset, default IP address is 10.1.1.10. If the **Reset Configuration** option is selected from HAFM, the director resets to the default address of 10.1.1.10.

If multiple directors are installed on the same LAN, each director (and appliance) must use a unique IP address. One director can use the factory-set address, but the addresses of the remaining directors require change.

Note: If multiple directors and the HAFM appliance are delivered in an HP-supplied equipment cabinet, all devices are configured with unique IP addresses that do not require change. The addresses require change only if multiple equipment cabinets are LAN-connected.

- **Subnet mask**—The subnet mask is 255.0.0.0. If the director is installed on a complex public LAN with one or more routers, the address may require change.
- **Gateway address**—The gateway address is 0.0.0.0. If the director is installed on a dedicated LAN with no connection through a router, the address does not require change. If the director is installed on a public LAN (corporate intranet), the gateway address must be changed to the address of the corporate intranet's local router.

Verify the type of LAN installation with the customer's network administrator. If one director is installed on a dedicated LAN, network addresses must be verified but do not require change.

Changing the Director's IP Address

If multiple directors are installed, or a public LAN segment is used, network addresses must be changed to conform to the customer's LAN addressing scheme. The following items are required to perform this task:


- A local workstation (desktop or notebook computer) with:
 - Microsoft Windows 98, Windows 2000, Windows 2003, Windows XP, Windows Millennium Edition, or Windows NT 4.0 operating system
 - RS-232 serial communication software (for example, ProComm Plus or HyperTerminal)

Note that the HAFM appliance may be used for this function and that HyperTerminal is included in Windows 2000 provided in the HAFM appliance.

- An asynchronous RS-232 null modem cable (supplied with the Director 2/64)

Use the following steps to verify or change (if required) a director IP address, subnet mask, or gateway address:

1. Remove the protective cap from the 9-pin maintenance port at the rear of the director (a flat-tip screwdriver may be required). See [Figure 31](#) ❶.



SHR-2283

- ❶ Maintenance port
- ❷ RS-232 port

- ❸ Null Modem cable

Figure 31: Connecting the null modem cable between the director and a workstation

2. Connect the 9-pin end of the RS-232 modem cable to the maintenance port.
3. Connect the other cable end to a 9-pin communication port (COM1 or COM2) at the rear of the local workstation.

4. Choose **Start > Programs > Accessories > Communications > HyperTerminal**. The Connection Description dialog box displays, as shown in [Figure 32](#).




Figure 32: Connection Description dialog box

5. Enter 264 in the **Name** field and click **OK**. The Connect To dialog box displays, as shown in [Figure 33](#).



Figure 33: Connect To dialog box

6. Ensure the **Connect using** field displays COM1 or COM2 (depending on the serial communication port connection to the director) and click **OK**. The COMn Properties dialog box displays, as shown in [Figure 34](#).




Figure 34: COMn Properties dialog box

7. Configure the Port Settings parameters as follows:
 - Bits per second: 115200
 - Data bits: 8
 - Parity: None
 - Stop bits: 1
 - Flow control: Hardware
8. Click **OK**. The HyperTerminal window displays.
9. At the > prompt, enter the user-level password (the default is password) and press the **Enter** key. The password is case-sensitive. The HyperTerminal window displays with a C> prompt at the top of the window.
10. At the C> prompt, enter `ipconfig` and press **Enter**. The HyperTerminal window displays, as shown in [Figure 35](#).
 - MAC Address
 - IP Address (default is 10.1.1.10)
 - Subnet Mask (default is 255.0.0.0)
 - Gateway Address (default is 0.0.0.0)
 - Auto Negotiate
 - Speed
 - Duplex

Only the **IP Address**, **Subnet Mask**, and **Gateway Address** fields are configurable.




Figure 35: HyperTerminal window

11. To change director network addresses, enter the following at the C> prompt and press **Enter**.

```
ipconfig xxx.xxx.xxx.xxx.yyy.yyy.yyy.yyy.zzz.zzz.zzz.zzz
```

The IP address format is xxx.xxx.xxx.xxx. The subnet mask format is yyy.yyy.yyy.yyy. The gateway address format is zzz.zzz.zzz.zzz. The octets xxx, yyy, and zzz are decimals from 0 through 255. If a network address is to remain unchanged, enter the current address in the respective field.

When the new network addresses are configured at the director, the message Request completed OK displays at the bottom of the HyperTerminal window.

12. Choose **Exit** from the **File** drop-down menu. A HyperTerminal dialog box displays, as shown in [Figure 36](#).




Figure 36: HyperTerminal dialog box (1)

13. Click **Yes**. A second HyperTerminal dialog box displays, as shown in [Figure 37](#).





Figure 37: HyperTerminal dialog box (2)

14. Click **No** to exit and close the *HyperTerminal* application.
15. Power off the maintenance terminal:
 - a. Choose **Start > Shut Down**. The Shut Down Windows dialog box displays.
 - b. Choose **Shut down** and click **Ok** to power off the PC.
16. Disconnect the RS-232 null modem cable from the director and the maintenance terminal. Replace the protective cap over the maintenance port.

LAN-Connect the Director

Use these steps to connect the rack-mounted director to the Ethernet LAN segment.

1. Connect one end of an Ethernet cable to the RJ-45 connector on each CTP2 card, as shown in [Figure 38](#).



SHR-2275

- | | |
|--|---|
| ① Remote workstation | ③ HAFM appliance (laptop or rack-mount) |
| ② Ethernet hub or switch (customer supplied) | ④ Director 2/64 |

Figure 38: LAN-connect the director

2. Connect the remaining end of each Ethernet cable to the LAN as directed by the customer's network administrator.

Note: If an HAFM appliance is not available, use the Embedded Web Server (EWS) interface. Attach the Ethernet LAN segment to an Internet connection.

HAFM Appliance

To run HAFM software, you must set up and configure the HAFM appliance. Refer to the *HP StorageWorks HA-Fabric Manager Appliance Installation Guide* for instructions on:

- Setting up the HAFM appliance
- Connecting the HAFM appliance to the LAN
- Configuring the network addresses and passwords for the HAFM appliance
- Setting HAFM appliance date and time
- Configuring and enabling event notification features
- Creating HAFM user names and passwords

Element Manager **Enabling HAFM to Manage the Director**

To manage a new director, it must be recognized by the *HAFM* application. Follow these steps to enable HAFM to recognize a new director:

1. At the *HAFM* application, choose **Discover > Setup**. The Discover Setup dialog box displays, as shown in [Figure 39](#).




Figure 39: Discover Setup dialog box

2. Click **Add**. The Domain Information dialog box displays with the **IP Address** page open, as shown in [Figure 40](#).




Figure 40: Domain Information dialog box (IP Address page)

3. Enter a director description in the **Description** field.
4. Enter the IP address you configured earlier. See “[Configure Director Network Information](#)” on page 70 for more information.
5. Enter the director subnet mask (determined by the customer network administrator) in the **Subnet Mask** field.
6. If you want to generate a sequence of IP addresses, perform the following:
 - Choose the **Generate a sequence of IP addresses** check box.
 - Enter the last IP address in the **Last IP** field.

Note: All IP addresses in a sequence must be on the same subnet and have the same first three octets.




7. Click **OK**.

Verify Communication Between the Director and HAFM Appliance

Follow these steps to check director-to-server communication:

1. At the *HAFM* application main window (physical map or product list), inspect the shape and color of the status symbol associated with the director icon. [Table 6](#) explains these symbols.

Table 6: Director Operational States and Symbols

Operational State	Symbol
Operational —Director-to-server communication has been established, the director is operational, and no failures are indicated.	No Status Symbol
Degraded —Director-to-server communication has been established, but the director is operating in degraded mode and requires service. This condition is typical if a port or redundant FRU fails. Go to step 2 .	
Failed —Director-to-server communication has been established, but the director failed and requires immediate service. Go to step 2 .	
Status Unknown —The director status is unknown because of a network communication failure between the director and HAFM appliance. Go to step 2 .	

2. Right-click the **Director 64** icon. A pop-up menu for the selected director displays, as shown in [Figure 41](#).
In the example, the director's status is operational as indicated by the green circle in the alert panel.
3. Check director status at the **Hardware View** page and complete one of the following steps:
 - a. If the director displays as operational (no FRU alert symbols), go to "[Configuring Feature Key](#)" on page 107.
 - b. If director operation displays as degraded or a director failure is indicated (FRU alert symbols and a yellow triangle or red diamond at the alert panel), refer to the *HP StorageWorks Director 2/64 Service Manual*.




Figure 41: Hardware View page (with FRU failures)

Set Director Date and Time

The Director Element Manager log entries are stamped with the date and time received from the director. Use these steps to set the effective date and time for the director:

Note: The director and HAFM synchronize at least once daily.

1. At the **Hardware View**, choose **Configure > Date/Time**. The Configure Date and Time dialog box displays, as shown in [Figure 42](#).
2. Set director date and time manually, or set for periodic updates. For specific instructions, see the following sections:
 - [Set Director Date and Time](#), page 81
 - [Synchronize Date and Time](#), page 82



Figure 42: Configure Date and Time dialog box

Set Date and Time Manually

Use these steps to set the director date and time manually:

1. At the Configure Date and Time dialog box, click the **Periodic Date/Time Synchronization** check box to deselect the option (no check mark in the box). The grayed-out **Date** and **Time** fields activate.
2. Click the **Date** fields that require change, and enter numbers in the following ranges:
Month (MM): 1 through 12
Day (DD): 1 through 31
Year (YYYY): greater than 1980
3. Click the **Time** fields that require change, and enter numbers in the following ranges:
Hour (HH): 0 through 23
Minute (MM): 0 through 59
Second (SS): 0 through 59
4. Click **Activate** to set the director date and time.

Synchronize Date and Time

Use these steps to set the director to periodically synchronize date and time with HAFM:

1. At the Configure Date and Time dialog box, choose the **Periodic Date/Time Synchronization** check box. The **Date** and **Time** fields are grayed-out and not selectable.
2. Click **Activate** to enable synchronization. The director date and time synchronize with the HAFM date and time at the next update period (at least once daily).

3. Click **Sync Now** to synchronize the director and HAFM immediately. The Date and Time Synced dialog box displays.




Figure 43: Date and Time Synced dialog box

4. Click **OK**.
5. Click **Activate** to enable synchronization.

Frequently Used HAFM Settings

This section summarizes the most common HAFM tasks including:

Note: For a complete reference on HAFM functionality, refer to the *HP StorageWorks HA-Fabric Manager User Guide*.

- [Setting the Director Online](#), page 85
- [Setting the Director Offline](#), page 85
- [Configuring Director Identification](#), page 85
- [Configuring Director Management Style](#), page 86
- [Configuring Switch Parameters](#), page 87
- [Configuring Fabric Parameters](#), page 91
- [Configuring Preferred Path](#), page 94
- [Configuring Switch Binding](#), page 94
- [Configuring Ports](#), page 94
- [Configuring Port Addresses \(FICON\)](#), page 96
- [Configuring SNMP Trap Message Recipients](#), page 96
- [Configuring and Enabling E-mail Notification](#), page 97
- [Configuring and Enabling Call-Home Features](#), page 100
- [Configuring and Enabling Ethernet Events](#), page 100
- [Configuring Threshold Alerts](#), page 101
- [Backing Up HAFM Configuration Data](#), page 107
- [Configuring Open Systems Management Server](#), page 107
- [Configuring FICON Management Server](#), page 107
- [Configuring Feature Key](#), page 107
- [Configuring Open Trunking](#), page 108
- [Enabling Embedded Web Server](#), page 108
- [Enabling Telnet](#), page 108

Setting the Director Online

When the director is set online, an attached device can log into the director if the port is not blocked. Attached devices can communicate with each other if they are configured in the same zone. Use these steps to set the director online:

1. Open HAFM. The View All - HAFM 8 page displays.
2. Double-click the appropriate director icon. The **Hardware View** page for the selected director displays.
3. Choose **Maintenance > Set Online State**. If the director is offline, the Set Online State dialog box displays, indicating the status is Offline.
4. Click **Set Online**. A Warning dialog box displays, indicating status is online.
5. Click **OK**. The **Status** table displays Online.

Setting the Director Offline

When the Director is set offline, all ports are set offline. The director transmits the offline sequence (OLS) to attached devices, and the devices cannot log in to the director. Use these steps to set the director offline:

1. Notify the customer that the director is going offline.
1. Open HAFM. The View All - HAFM 8 page displays.
2. Choose the appropriate director icon. The **Hardware View** page for the selected director displays.
3. Choose **Maintenance > Set Online State**. If the director is online, the Set Online State dialog box displays, indicating the status is Online.
4. Click **Set Offline**. A Warning dialog box displays, indicating the director will be set offline.
5. Click **OK**.

Configuring Director Identification

Perform this procedure to configure the director name, description, location, and contact person for HAFM. The information displays in multiple dialog boxes throughout the application. In addition, the **Name**, **Location**, and **Contact** variables configured in the **Configure Identification** dialog box correspond respectively to the SNMP variables **sysName**, **sysLocation**, and **sysContact**. These variables are used by SNMP management workstations when obtaining data from managed directors.

Follow these steps to configure the director identification:

1. At the **Hardware View** page, choose **Configure > Identification**. The Configure Identification dialog box displays, as shown in [Figure 44](#).




Figure 44: Configure Identification dialog box

2. Enter a director name of 24 or fewer alphanumeric characters in the **Name** field. Each director should be configured with a unique name.
3. If the director is installed on a public LAN, the name should reflect the director's Ethernet network DNS host name. For example, if the DNS host name is SAN64.hp.com, the name entered in this dialog box is SAN64.
4. Enter a director description of 255 or fewer alphanumeric characters in the **Description** field.
5. Enter the director's physical location (255 or fewer alphanumeric characters) in the **Location** field.
6. Enter the name of a contact person (255 or fewer alphanumeric characters) in the **Contact** field.
7. Click **Set Name as Nickname** to add a check mark to the check box if you want to use the name in the **Name** field as a nickname for the director WWN. The nickname displays instead of the WWN in Element Manager views.
8. Click **Activate** to save the information and close the dialog box.

Configuring Director Management Style

Note: To change this value, you must first set the director offline. Be sure to set the director back online after you change this value.

Perform this procedure to set the director to open systems or FICON management style. This setting only affects the management style used to manage the director; it does not affect port operation. OSI devices can communicate with each other if

the director is set to FICON management style, and FICON devices can communicate with each other if the director is set to open systems management style.

Note: If the FICON management server feature is enabled, the default management style is FICON. Open systems management style cannot be enabled.

To configure the director management style:

1. Ensure the director is set offline. For instructions, see “[Setting the Director Offline](#)” on page 85.
2. Choose **Product > Management Style**. The **Configure Management** menu displays.
3. Choose the management style as follows:
 - Use **Open Systems** for all other (non-FICON) Fibre Channel environments.
 - If the FICON Management Server feature is enabled, the default style will be **FICON**. The management style cannot be changed to Open Systems with the FICON Management Server feature enabled. Typically, FICON management style is used when attaching an IBM S/390 Parallel Enterprise or IBM zSeries server to the switch and implementing inband switch management through a Fibre Connection (FICON) channel.
4. Set the director online. For instructions, see “[Setting the Director Online](#)” on page 85.

Configuring Switch Parameters

Use the procedures in this section to set parameters on the director for fabric operation through the Configure Switch Parameters dialog box. These parameters are stored in NV-RAM on the director.

1. The director must be offline to change **Preferred Domain ID** parameter. Verify that the director is set offline. For instructions, see “[Setting the Director Offline](#)” on page 85.



Caution: Setting the director offline terminates all Fibre Channel connections.

2. Choose **Configure > Operating Parameters > Switch Parameters**. The Configure Switch Parameters dialog box displays, as shown in [Figure 45](#).




Figure 45: Configure Switch Parameters dialog box

Ordinarily, you do not need to change values in this dialog box from their defaults. The only exception is the **Preferred Domain ID**. Change this value if the director will participate in a multi-switch fabric.

3. Use information under “[Switch Parameters](#)” to change settings as required for parameters in this dialog box.
4. After you change settings, click the **Activate** button.
5. Set the director online. For instructions, see “[Setting the Director Online](#)” on page 85.

Switch Parameters

Configure the following parameters as required by your fabric.

Domain ID

The domain identification is a value between 1 and 31 that provides a unique identification for the director in a fabric. A fabric director cannot contain the same domain ID as another director or their E_Ports will segment when they try to join.

In the **Configure Switch Parameters** dialog box, a field is provided to enter a preferred domain ID and a check box is provided to enable this ID as an insistent domain ID.

Preferred

Note: To change this value, you must first set the director offline. Be sure to set the director back online after you change this value.

Use this field to set a unique domain ID for the director. The default value is 1. Set a value between 1 and 31. When a director comes online with a preferred ID, it requests an ID from the fabric's principal director (indicating its preferred value as part of the request). If the requested domain ID is not allocated to the fabric, the domain ID is assigned to the requesting director. If the requested domain ID is already allocated, an unused domain ID is assigned. Note that you must set the director offline before you can change to the preferred domain ID.

The preferred domain ID must be unique for each director and switch in a fabric. If two switches or directors have the same preferred domain ID, the E_Ports segment, causing the fabric to segment.

For more information on domain ID, refer to the section on domain ID assignment for multi-switch fabrics in the *HP StorageWorks SAN High Availability Planning Guide* for details.

Insistent

This option is not supported unless the SANtegrity Binding feature is installed. Click the check box to remove or add a check mark. The default state is disabled (no check mark).

When a check mark displays, the domain ID configured in the **Preferred Domain ID** field will become the active domain identification when the fabric initializes. See the following notes:

- This option is required if **Enterprise Fabric Mode** (optional SANtegrity Binding feature) is enabled.
- If you enable **Insistent Domain** while the switch or director is online, the **Preferred Domain ID** will change to the current active domain ID if the IDs are different.



Caution: If a director with a duplicate domain ID exists in the fabric, both directors' E_Ports will segment when they try to join.

Rerouting Delay

Placing a check mark in the check box to the left of the **Rerouting Delay** option enables rerouting delay. This option is only applicable if the configured director is in a multi-switch fabric. The default state is enabled.

Enabling the rerouting delay ensures that frames are delivered in order through the fabric to their destination. If there is a change to the fabric topology that creates a new path (for example, a new director is added to the fabric), frames may be

routed over this new path if its hop count is less than a previous path with a minimum hop count. This may result in frames being delivered to a destination out of order since frames sent over the new, shorter path may arrive ahead of older frames still in route over the older path.

If rerouting delay is enabled, traffic ceases in the fabric for the time specified in the **E_D_TOV** field of the Configure Fabric Parameters dialog box. This delay allows frames sent on the old path to exit to their destination before new frames begin traversing the new path.

Note: This option is required if Enterprise Fabric Mode (optional SANtegrity Binding feature) is enabled.

Domain RSCNs

Domain register for state change notifications (domain RSCNs) are sent between end devices in a fabric to provide additional connection information to host bus adapters (HBA) and storage devices. As an example, this information might be that a logical path has been broken because of a physical event, such as a fiber optic cable being disconnected from a port. Consult with your HBA and storage device vendor to determine if enabling Domain RSCNs will cause problems with your HBA or storage products. Note that this option is required if Enterprise Fabric Mode (optional SANtegrity Binding feature) is enabled.

Suppress RSCN's on Zone Set Activations

Fabric format domain register for state change notifications (RSCNs) are sent to ports on the switch following any change to the fabric's active zone set. These changes include activating and deactivating the zone set, or enabling and disabling the default zone. When the **Suppress RSCNs on Zone Set Activations** check box is selected, fabric format RSCNs are not sent for zone changes to the attached devices on the switch. Click the check box to remove or add a checkmark.

This option is disabled (check box not selected) by default. In most cases this option should be enabled so that attached devices can receive notification of zoning changes in the fabric. However, some HBAs may log out, then log back into the fabric when they receive an RSCN, thereby disrupting Fibre Channel traffic. Consult with your HBA and storage device vendor to determine if disabling this option (and thereby enabling RSCN transmission) will cause problems with your HBA or storage products.

Director Speed

At the **Director Speed** field, choose 1 Gb/sec or 2 Gb/sec to select the speed of Fibre Channel operation.

Note: Changing the switch speed to 2 Gb/s with any 1 Gb/s FPM cards installed will cause the following warning/confirmation message to display: “All FPM ports will be held inactive while the switch is configured to 2 Gb/sec speed. Do you want to continue?”

Configuring Fabric Parameters

Use procedures in this section to set parameters on the director for fabric operation through the Configure Fabric Parameters dialog box. These parameters are stored in NV-RAM on the director.

1. Verify that the director is set offline. For instructions, see “[Setting the Director Offline](#)” on page 85.



Caution: Setting the director offline terminates all Fibre Channel connections.

2. Choose **Configure > Operating Parameters > Fabric Parameters**. The Configure Fabric Parameters dialog box displays, as shown in [Figure 46](#).




Figure 46: Configure Fabric Parameters dialog box

3. Use information under “[Fabric Parameters](#)” to change settings as required for parameters in this dialog box.
4. After you change settings, click the **Activate** button.

5. Back up the configuration data when you are finished configuring the switch.
6. Set the director online. For instructions, see “[Setting the Director Online](#)” on page 85.

Fabric Parameters

Configure the following parameters as required by your fabric.

BB_Credit

Configure the director to support buffer-to-buffer credit (BB_Credit) from 1 through 60. This is the value used for all ports, except those configured for extended distance buffering (10-100 km). The default value is 16. For a description of the buffer-to-buffer credit, refer to the industry specification, *Fibre Channel Physical and Signaling Interface*.

R_A_TOV

Configure resource allocation time-out value (R_A_TOV) in tenth-of-a-second increments. This variable works with the error detect time-out value (E_D_TOV) variable to control the director's behavior when an error condition occurs. Resources are allocated to a circuit when errors are detected and are not released for reuse until the time set by the R_A_TOV value expires. The default value is 100 tenths (10 seconds). Set a value between 10 tenths and 1200 tenths (1 through 120 seconds).

Note: Set the same value for R_A_TOV on all directors and edge switches in a multi-switch fabric. If the value is not the same on all units, the fabric segments. Also, the value for R_A_TOV must be greater than the value configured for E_D_TOV.

E_D_TOV

Adjust the E_D_TOV in tenth-of-a-second increments. An error condition occurs when an expected response is not received within the time limit set by this value. The default value is 20 tenths (2 seconds). Set a value between 2 tenths through 600 tenths (.2 through 60 seconds).

Note: Set the same value for E_D_TOV on all switches and directors in a multi-switch fabric. If the value is not the same, the fabric segments.

Switch Priority

Setting this value determines the principal director for the multi-switch fabric. Choose **Principal** (highest priority), **Default**, or **Never Principal** (lowest priority) from the **Switch Priority** drop-down list.

Setting these priority values determines the principal director selected for the multi-switch fabric. For example, if you have three directors in the fabric and set one as **Principal**, one as **Default**, and one as **Never Principal**, the unit set to **Principal** becomes the principal director in the fabric.

If all directors are set to **Principal** or **Default**, the director with the highest priority and the lowest WWN becomes the principal director. The following are some examples of principal director selection when directors have these settings:

- If you have three directors and set all to **Default**, the director with the lowest WWN becomes the principal director.
- If you have three directors and set two to **Principal** and one to **Default**, the director with the **Principal** setting that has the lowest WWN becomes the principal director.
- If you have three directors and set two to **Default** and one to **Never Principal**, the director with the **Default** setting and the lowest WWN becomes the principal director.

At least one director in a multi-switch fabric needs to be set as **Principal** or **Default**. If all of the directors are set to **Never Principal**, all of the interswitch links (ISLs) will segment. If all but one director is set to **Never Principal** and the director that was principal goes offline, then all of the other ISLs will segment.

Note: We recommend you leave the switch priority setting as Default. If you are considering setting this value to something other than default, refer to the section on principal switch selection for multi-switch fabrics in the *HP StorageWorks SAN High Availability Planning Guide* for details.

For example, in the audit log, you may notice that the **Principal** setting maps to a number code of 1, **Default** maps to a number code of 254, and **Never Principal** maps to a number code of 255. The number codes of 2-253 are not currently in use.

Interop Mode

Choose one of the following options:

- **Homogeneous Fabric**—Choose this mode if the fabric contains only HP directors and edge switches that are operating in Homogeneous Fabric mode.
- **Open Fabric 1.0**—Default. Choose this mode if the fabric contains HP directors and edge switches, as well as other open-fabric compliant switches. Choose this mode for managing heterogeneous fabrics.

Configuring Preferred Path

The preferred path feature allows a user to specify and configure one or more ISL data paths between multiple directors or switches in a fabric. Each participating director or switch must be configured as part of a desired path. For complete procedures on configuring this optional feature, refer to *HP StorageWorks Director Element Manager User Guide*.

Configuring Switch Binding

This feature is managed through the **Switch Binding** submenu options available on the Element Manager **Configure** menu. Using **Switch Binding**, you can specify devices and switches that can attach to director and switch ports. This provides security in environments that include a large number of devices by ensuring that only the intended set of devices attach to a switch or director. For complete procedures on configuring this optional feature, refer to *HP StorageWorks Director Element Manager User Guide*.

Configuring Ports

Perform this procedure to define Fibre Channel port names, configure ports as blocked or unblocked, enable extended distance operation and Link Incident (LIN) alerts, and define port types.

1. At the **Hardware View** page, choose **Configure > Ports**. The Configure Ports dialog box displays.
 - a. Choose a blank **Name** field and enter a descriptive port name of 24 or fewer alphanumeric characters. Use a unique name that reflects the device connected to the port. This name will be associated with the port and will not change regardless of the device connected.
 - b. Click the **Blocked** check box to block or unblock a port, as shown in [Figure 47](#). A check mark in the box indicates that the port is blocked. Blocking the port prevents the attached device from communicating with the director. A blocked port continuously transmits the offline sequence.

Port #	Name	Blocked	10-100 km	LIN Alerts	Type	Speed	Port Binding	Bound VVNN
0		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
1		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
2		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
3		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
4		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
5		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
6		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
7		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
8		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
9		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
10		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
11		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
12		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
13		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
14		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
15		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
16		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
17		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
18		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
19		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
20		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
21		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
22		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	
23		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	G_Port	Negotiate	<input type="checkbox"/>	

Figure 47: Configure Ports check boxes

- c. Click the **10-100 km** check box to enable extended distance buffering for a port. A check mark in the box indicates the extended distance operation up to 100 kilometers (through repeaters) is enabled.
- d. Click the **LIN Alerts** check box to enable or disable LIN alerts for a port. A check mark in the box indicates alerts are enabled. When the feature is enabled and an incident occurs on the link, an alert indicator (yellow triangle) displays at the **Hardware View**, **Port List View**, and **Port Card View** pages, and a message is sent to configured e-mail recipients. LIN alerts are enabled by default.
- e. Choose a **Type** field and choose generic port (**G_Port**), fabric port (**F_Port**), or expansion port (**E_Port**) from the list box. If **F_Port** or **E_Port** is selected, the port will only operate as the port type selected. If **G_Port** is selected, the port type is automatically detected and will operate as an E_Port or F_Port.
- f. Click the **Speed** field for a port. A **Speed** drop-down list displays. Choose **1 Gig**, **2 Gig**, or **Negotiate** as the desired setting depending on the speed capability of the device to be plugged into the port. A right-click in the **Speed** column will allow selecting from a pop-up menu to set all ports to 1 Gb/sec, 2 Gb/sec, or Negotiate.

- g. Click the **Port Binding** check box to enable WWN binding for the port, which allows only a specific device to attach to the port. This device is specified by the WWN or nickname entered into the **Bound WWN** column. With the check box cleared, any device can attach to the port even if a WWN or nickname is specified in the **Bound WWN** column.
 - h. In the **Bound WWN** field, enter a world wide name (WWN) in the correct format (xx.xx.xx.xx.xx.xx.xx.xx) or a nickname configured through the Element Manager. If **Port Binding** is enabled, the device with this WWN or nickname has exclusive attachment to the port. If **Port Binding** is enabled but an invalid WWN or nickname is entered in this field, no device can connect to the port. If a valid WWN or nickname is entered but the **Port Binding** is not checked, the WWN or nickname is stored and all devices can connect to the port.
2. Use the vertical scroll bar as necessary to display additional port information rows (up to 64 ports).
3. Click **Activate** to save the configuration information and close the dialog box. If any port speed was changed, an information message box displays stating, "Port speed changes will temporarily disrupt port data transfers. Would you like to continue?" Click **Yes** to complete activation.

Configuring Port Addresses (FICON)

If the director is set to FICON management style, perform this procedure to access the director matrix and define Fibre Channel port names, configure ports as blocked or unblocked, and define the CUP name. For instructions on configuring port addresses, refer to *HP StorageWorks Director Element Manager User Guide* for details.

Configuring SNMP Trap Message Recipients

Use this procedure to configure community names, write authorizations, network addresses, and UDP port number for up to 12 SNMP trap message recipients. A trap recipient is a management workstation that receives notification through SNMP.

1. At the **Hardware View** page, choose **Configure > SNMP Agent**. The Configure SNMP dialog box displays, as shown in [Figure 48](#).




Figure 48: Configure SNMP dialog box

- a. For each trap recipient to be configured, enter a community name of 32 or fewer alphanumeric characters in the associated **Community Name** field. The community name is incorporated in SNMP trap messages to ensure against unauthorized viewing or use.
 - b. Click the check box in the **Write Authorization** column to enable or disable write authorization for the trap recipient (default is disabled). A check mark in the box indicates write authorization is enabled. When the feature is enabled, a management workstation user can change the HAFM appliance's **sysContact**, **sysName**, and **sysLocation** SNMP variables.
 - c. Enter the IP address or DNS host name of the trap recipient (SNMP management workstation) in the associated **Trap Recipient** field. Use 64 or fewer alphanumeric characters. Hewlett-Packard recommends using the IP address.
 - d. Enter a decimal user datagram protocol (UDP) port number in the associated **UDP Port Number** field. (This number is commonly 162.)
2. To enable transmission of trap messages to configured SNMP management workstations, click **Enable Authorization Traps**. A check mark displays in the box when transmission is enabled.
 3. Click **Activate** to save the information and close the dialog box.

Configuring and Enabling E-mail Notification

Use this procedure to configure and enable e-mail addresses and Simple Mail Transfer Protocol (SMTP) server addresses to receive e-mail notification of director (and other managed product) events. The addresses must be configured via HAFM, then enabled.

Use these steps to configure and enable e-mail and SMTP server addresses:

1. At the HAFM main page, choose **Monitor > Event Notification > E-Mail**. The E-Mail Event Notification Setup dialog box displays, as shown in [Figure 49](#).




Figure 49: E-Mail Event Notification Setup dialog box

2. To enable e-mail transmission of configured addresses, click **Enable E-Mail Event Notification**. A check mark displays in the box when transmission is enabled.

Note: The enable function must also be activated for each director or switch through the Element Manager. E-mail notification can be active for some directors or switches and inactive for others.

3. Enter the IP address or DNS host name of the SMTP server in the **E-mail Server** field. Use 64 or fewer alphanumeric characters.
4. Enter the e-mail address to which e-mail replies should be sent in the **Reply** field.
5. At the **Interval** field, enter the length of time the application should wait between notifications. Choose **seconds**, **minutes**, or **hours** from the associated drop-down list.
6. To specify users that are to receive e-mail notification, click **User List**. The HAFM 8 Server Users dialog box displays, as shown in [Figure 50](#).




Figure 50: HAFM 8 Server Users dialog box

7. To enable e-mail notification for a user, choose the check box in the **Email** column. An unchecked box indicates e-mail notification is not enabled.
8. To configure event types for which e-mail notification is sent, choose the **Filter** link adjacent to the check box. The Define Filter dialog box displays.




Figure 51: Define Filter dialog box

9. Choose the filters that you want for this user.
10. Click **OK** to close the Define Filter dialog box.
11. Click **OK** to close the HAFM 8 Server Users dialog box.

12. Click **Test Email**. A test message is sent to configured e-mail recipients.
13. Click **OK** to save the information and close the Email Event Notification Setup dialog box.
14. Maximize the Hardware View (Element Manager).
15. At the Hardware View, choose **Maintenance > Enable E-Mail Notification**. A check mark displays in the check box to indicate e-mail notification for the director is enabled, and the menu closes.

Note: Using HAFM, enable or disable e-mail event notification for each director individually.

Configuring and Enabling Call-Home Features

There are two call-home features available, and only one is installed when the *HAFM* application is installed on the HAFM appliance. To learn more about configuring call-home features, refer to the *HP StorageWorks HA-Fabric Manager Appliance Installation Guide*.

Configuring and Enabling Ethernet Events

Perform this procedure to configure and enable Ethernet events. An Ethernet event is recorded (after a user-specified time interval) when the director-to-HAFM appliance communication link drops. To configure and enable Ethernet events:

1. Choose **Monitor > Ethernet Event**. The Configure Ethernet Event dialog box displays, as shown in [Figure 52](#).




Figure 52: Configure Ethernet Event dialog box

2. Click the **Enable Ethernet Events** check box. A check mark displays in the check box to indicate Ethernet events are enabled.
3. Enter a value between **10** through **120** minutes in the **Ethernet Timeout** field.
4. Click **OK** to close the dialog box.

Configuring Threshold Alerts

A threshold alert notifies users when the transmit (Tx) or receive (Rx) throughput reaches specified values for specific director ports or port types, (E_Ports or F_Ports). You are notified of a threshold alert by:

- A yellow triangle that displays on the port in the **Port Card View**.
- A yellow triangle that displays on the port in the **Hardware View**.
- A yellow triangle that displays in the **Alert** column of the **Port List View**.
- A yellow triangle that displays by the **Threshold Alerts** field in the **Port Properties** dialog box.
- Detailed threshold alert data recorded in the Threshold Alert Log.

Use the **Threshold Alerts** option on the **Configure** menu to configure the following:

- Name for the alert.
- Type of threshold for the alert (Rx, Tx, or either).
- Active or inactive state of the alert.
- Threshold criteria:
 - Percent traffic capacity utilized—The percent of the port's throughput capacity achieved by the measured throughput. This setting constitutes the threshold value. For example, a value of 50 means that the port's threshold is reached when throughput is 50% of capacity.
 - Time interval during which throughput is measured and alert notification can occur.
 - The maximum cumulative time that the throughput percentage threshold can be exceeded during the set time interval before an alert is generated.
- Ports for which you are configuring threshold alerts.

You can configure up to 16 alerts, and any number of alerts can be active at one time. Use the following procedures to create a new threshold alert, or to modify, activate, deactivate, or delete an alert.

Creating New Alerts

1. At the **Hardware View** page, choose **Configure > Threshold Alerts**. The Configure Threshold Alerts dialog box displays, as shown in [Figure 53](#).

Note: If alerts are configured, they will display in table format showing the name of the alert, type of alert (Rx, Tx, or Rx or Tx), and alert state (inactive or active).




Figure 53: Configure Threshold Alerts dialog box

2. Click **New**. The New Threshold Alert dialog box displays, as shown in [Figure 54](#).




Figure 54: New Threshold Alerts dialog box—first screen

3. Enter a name from one to 64 characters in length. All characters in the ISO Latin-1 character set, excluding control characters, are allowed.

4. Choose one of the following from the drop-down list under the **Name** field:
 - **Rx Throughput**—An alert will occur if the threshold set for receive throughput is reached.
 - **Tx Throughput**—An alert will occur if the threshold set for transmit throughput is reached.
 - **Rx or Tx Throughput**—An alert will occur if the threshold set for either receive or transmit throughput is reached.
5. Click **Next**. A new screen displays with additional parameters, as shown in [Figure 55](#). The name configured for the alert displays at the top of the screen.

Note: Click Previous if you need to return to the previous screen.

Figure 55: New Threshold Alerts dialog box—second screen

6. Enter a percentage from 1 through 100 for % utilization. When throughput reaches this percentage of port capacity, a threshold alert will occur.
7. Enter the amount of cumulative minutes in which the % utilization should exist during the notification interval before an alert is generated. You can also choose **At any time** if you want an alert to occur whenever the set % utilization is reached. The valid range is from 1 to the interval value set in [step 8](#).

8. Enter the interval in minutes in which throughput is measured and threshold notifications can occur. The valid range is 5 minutes to 70,560 minutes.
9. Click **Next**. A new screen displays for selecting ports for the alerts, as shown in [Figure 56](#).




Figure 56: New Threshold Alerts dialog box—third screen

10. Choose either **Port Type** or **Port List**.
 - For **Port Type**, choosing either E_Ports or F_Ports will cause this alert to generate for all ports configured as E_Ports or F_Ports, respectively.
 - For **Port List**, you can choose individual ports by clicking the check box by each port number or set all ports. Selecting **Set All Ports** places a check mark by each port number. Selecting **Clear All Ports** will clear the check marks by each port number.
11. Click **Next**. A final screen displays to provide a summary of your alert configuration, as shown in [Figure 57](#).




Figure 57: New Threshold Alerts dialog box—summary screen

12. Click **Finish**. The Configure Threshold Alerts dialog box displays, as shown in [Figure 58](#).




Figure 58: Configure Threshold Alerts dialog box

13. At this point, the alert is not active. To activate the alert, choose the alert information that displays in the **Configure Threshold Alerts** table and click **Activate**. The alert is activated.

Modifying Alerts

Use the following steps to modify an existing threshold alert configuration.

1. At the **Hardware View** page, choose **Configure > Threshold Alerts**. The Configure Threshold Alerts dialog box displays.
Choose the alert that you want to modify by clicking the alert information in the table. If the alert is active, an error message displays prompting you to deactivate the alert.
2. If the alert is active, click **Deactivate**, then choose the alert information in the table again.
3. Click **Modify**. An initial Modify Threshold dialog box displays, where you can change the threshold type.
4. Choose a threshold type from the drop-down list.
5. Click **Next** when you are done. A Modify Threshold dialog box displays, where you can change the % utilization, cumulative minutes for the threshold to occur before notification, and the time interval for measuring throughput and for alert notification.
6. Make appropriate changes, then continue through the Modify Threshold dialog boxes, making changes as necessary, until the summary screen displays the alert configuration.
7. Perform either of the following steps:
 - If you need to change any parameters, click **Previous** or **Next** to display the desired Modify Threshold dialog box.
 - Click **Finish** when you are done.

Activating or Deactivating Alerts

Use the following steps to activate or deactivate existing threshold alerts. In the active state, notifications are generated for the alert. In the inactive state, notifications do not occur.

1. At the **Hardware View** page, choose **Configure > Threshold Alerts**. The Configure Threshold Alerts dialog box displays.
The port's current state, inactive or active, is listed under the **State** column.
2. To change the state, choose the alert using the alert information in the table.
3. If the alert is active, choose **Deactivate** to change to the inactive state. If the alert is inactive, choose **Activate** to change to the active state.

Deleting Alerts

Use the following steps to delete existing threshold alerts.

1. At the **Hardware View** page, choose **Configure > Threshold Alerts**. The Configure Threshold Alerts dialog box displays.
2. Choose the alert that you want to delete by selecting the alert information in the table and click **Delete**. A message displays asking you to confirm the deletion.
3. Click **Yes**. The alert is removed from the dialog box.

Backing Up HAFM Configuration Data

It is important to back up the HAFM configuration data. This data is used to restore the HAFM appliance operating environment in case of hard drive failure.

Refer to the *HP StorageWorks HA-Fabric Manager Appliance Installation Guide* for instructions on backing up the HAFM configuration data.

Once the HAFM configuration data is backed up, go to “[Connecting Cables to the Fibre Channel Ports](#)” on page 109.

Configuring Open Systems Management Server

For complete procedures on configuring this optional feature, refer to the *HP StorageWorks Director Element Manager User Guide*.

Configuring FICON Management Server

For complete procedures on configuring this optional feature, refer to the *HP StorageWorks Director Element Manager User Guide*.

Configuring Feature Key

For complete procedures on configuring this feature, refer to the *HP StorageWorks Director Element Manager User Guide*.

Configuring Open Trunking

This option is only available if the optional Open Trunking feature is installed. Choosing this option opens the Configure Open Trunking dialog box. For details on enabling Open Trunking and configuring such parameters as congestion thresholds for ports, event notification options, and low BB credit threshold, refer to the *HP StorageWorks Director Element Manager User Guide*.

Enabling Embedded Web Server

Use the following steps to enable EWS:

1. At the **Hardware View** page, choose **Configure > Enable Web Server**. Choosing **Enable Web Server** automatically places a check mark in the check box.
2. Choose **Enable Web Server** again to remove the check mark and disable the EWS interface. When disabled, remote users cannot access the interface.

For complete procedures on using EWS, refer to the *HP StorageWorks Embedded Web Server User Guide*.

Enabling Telnet


Use the following steps to enable Telnet:

1. At the **Hardware View**, choose **Configure > Enable Telnet**. Choosing **Enable Telnet** automatically places a check mark in the check box.
2. Choose **Enable Telnet** again to remove the check mark and disable telnet access. When disabled, remote users cannot access the director through telnet.

Connecting Cables to the Fibre Channel Ports

Use these steps to connect Fibre Channel port cables:

1. Route the fiber-optic cables from customer-specified devices to ports at the front of the director, as shown in [Figure 59](#).



❶ Director 2/64

❷ Fibre Channel cables

❸ Workstation

SHR-2271

Figure 59: Connect the Fibre Channel cables

2. Connect device cables to ports and route the cables through the cable management assembly at the bottom front of the director. Start with the center UPM cards (cards 7 and 8) adjacent to the CTP2 cards and work outward. In addition, start with the bottom port of each UPM card and work upward.
3. Bundle Fibre Channel cables from the director and other equipment (groups of 16 maximum) and secure them as directed by the customer.
4. Set the director online. For instructions, see [“Setting the Director Online”](#) on page 85.

Connecting the Director to a Fabric

To attach the director to a multi-switch fabric, connect the director to an E_Port of another director or switch. The E_Port to E_Port connection is referred to as an ISL.

Use these steps to fabric-attach the director and create an ISL:

1. Verify that the director is defined via HAFM. See [“Element Manager Enabling HAFM to Manage the Director”](#) on page 78.
2. Verify that the preferred domain ID for the director is unique and does not conflict with the ID of another director or switch participating in the fabric. To change the domain ID, see [“Configuring Fabric Parameters”](#) on page 91.
3. Verify that the R_A_TOV and E_D_TOV values for the director are identical to the values for all directors and edge switches participating in the fabric.
4. Route a multi-mode or single-mode fiber-optic cable (depending on the ISL distance between directors) between customer-specified E_Ports of both directors.
5. At the *HAFM* application physical map, right-click the director product icon, then choose *Element Manager* from the pop-up menu.
6. If required, click the **Hardware** tab. The **Hardware View** displays.
7. Double-click the graphical port connector used for the fabric ISL. The Port Properties dialog box displays, as shown in [Figure 60](#).




Figure 60: Port Properties dialog box

8. Verify that the **Link Incident** field displays *None*. If an ISL segmentation or other problem is indicated, consult the *HP StorageWorks Director 2/64 Service Manual* to isolate the problem. If no problems are indicated, installation is complete.

Unpacking, Inspecting, and Installing the Ethernet Hub (Optional)

The HAFM appliance and one or more directors connect through an Ethernet hub installed on a 10/100 Mbps LAN segment. One hub port is required to connect the HAFM appliance, and one hub port is required to connect each director. A combination of up to 48 HP directors or switches can be configured and managed by a single HAFM appliance, therefore multiple hubs may be required to provide sufficient port connections. These hubs must be connected in accordance with the hub manufacturer's specifications. HP recommends using a star or hub-and-spoke topology when connecting multiple hubs. The HAFM appliance must be connected to the center hub, and there should never be more than two hubs between the HAFM appliance and any director. Refer to the hub manufacturer's documentation for more detailed information.

For instructions to unpack and inspect one or more Ethernet hubs, and install the hubs in a desktop or rack-mount configuration, refer to the appropriate Ethernet hub documentation.

Using HAFM from a Remote Location

Using a standard Web browser, the client HAFM and Director Element Manager can be downloaded and installed on PCs or workstations that are LAN-attached to the HAFM appliance. Operators at these platforms can manage and monitor directors or switches controlled by the appliance. A maximum of 25 concurrent users can log in to the HAFM appliance.

Each client must have access to the LAN segment on which the HAFM appliance is installed. Director administrative functions are accessed through the LAN and appliance. Use this section to install the HAFM client on a remote workstation.

Remote Workstation Minimum Requirements

The Client HAFM and Element Manager download and install to remote workstations (from the HAFM appliance) using a standard Web browser. The applications operate on platforms that meet the following minimum system requirements:

- Desktop or notebook PC with color monitor, keyboard, and mouse, using an Intel Pentium III processor with a 700 MHz or greater clock speed, and using the Microsoft Windows 2000 (with service pack 5 or higher), Windows NT 4.0 (with service pack 6a), or Windows 2003 operating system.

Note: In order for HAFM to function properly, compatible versions must be installed on both the client and server machines.

- UNIX® Workstation with color monitor, keyboard, and mouse using:
 - Linux-based system using an Intel Pentium III processor with a 1 gigahertz (GHz) or greater clock speed, using the Red Hat® 7.3 or higher operating system.
 - Hewlett-Packard PA-RISC processor with a 400 MHz or greater clock speed, using the HP-UX 11 or higher operating system.
 - Sun Microsystems® UltraPARC-II processor with a 300 MHz or greater clock speed, using the Solaris Version 7.0 or higher operating system.
 - IBM POWER3-II® microprocessor with a 333 MHz or greater clock speed, using the AIX Version 4.3.3 or higher operating system.
- At least 150 MB (Windows-based) or 350 MB (UNIX-based) available on the internal hard drive.

- 512 MB or greater RAM.
- Video card supporting 256 colors at 800 x 600 pixel resolution.
- Ethernet network adapter.
- Java-enabled Internet browser, such as Microsoft Internet Explorer (Version 4.0 or later) or Netscape Navigator (Version 4.6 or later).

Installing HAFM Client on a Remote Workstation

Use these steps to install HAFM on a remote client:

1. Verify the workstation and the Ethernet LAN segment (with the Director attached) are connected through the Internet.
2. At the workstation, launch the browser application.
3. At the browser, enter the HAFM appliance IP address.
4. The HAFM splash screen displays with the following options, see [Figure 61](#).
 - a. **Install HAFM remote client application**—Choose this option to install the application for your workstation platform.
 - b. **Download SNMP MIB files**—The Management Information Base (MIB) files are provided in standard ASN.1 syntax and may be installed into the MIB database of any SNMPv2 compliant Network Management Station.




Figure 61: HAFM remote client install

5. To install the *HAFM remote client* application, scroll down to the information that pertains to your platform and follow the instructions provided.
6. After you have downloaded the installer executable, the **InstallAnywhere Wizard** displays. Follow the instructions provided to continue the installation.

Launching HAFM from the Remote Client

Use these steps to launch HAFM from a remote client:

1. Double-click the **HAFM** icon to launch HAFM. The HAFM 8 Log In dialog box displays, as shown in [Figure 62](#).

Note: The default Windows 2000 user name is **Administrator** and the default password is **password**. The user name and password are case-sensitive.




Figure 62: HAFM 8 Log In dialog box

2. Enter the HAFM appliance IP address in the **Network Address** field. If you are logging in to the local HAFM appliance, the HAFM appliance name is *localhost*.

The default address that displays in the **Network Address** field is the address of the last server accessed. Click the HAFM appliance arrow to see the network addresses of all HAFM appliances that were accessed from the computer you are logged into.

If you want to connect to an HAFM appliance that is not listed, enter the IP address in the **Network Address** field.

3. Enter your user name and password in the **User Name** and **Password** fields. User names and passwords are case-sensitive.

4. If you want your computer to save the login information, choose the **Save Password** option.
5. Click **Login**. The View All - HAFM 8 window displays, as shown in [Figure 63](#).




Figure 63: View All - HAFM 8 window

- 6.

Managing Firmware Versions

3

The Director 2/64 internal operating code is downloaded from the HAFM appliance and stored on a CTP2 card. Up to eight (8) versions can be stored on the HAFM appliance hard drive and made available for download to a director. This chapter contains information on the following firmware management tasks:

- [Determining a Director Firmware Version](#), page 118
- [Adding a Firmware Version](#), page 119
- [Modifying a Firmware Version Description](#), page 121
- [Deleting a Firmware Version](#), page 122
- [Downloading a Firmware Version to a Director](#), page 123
- [Backing Up the Director's Configuration](#), page 126

Determining a Director Firmware Version

Use these steps to determine the Director firmware version:

1. Open the *HAFM* application. The View All - HAFM 8 main window displays.
2. Double-click the icon representing the director to be inspected for firmware version. The **Hardware View** page for the selected director displays.
3. Choose **Maintenance > Firmware Library**. The Director Firmware Library dialog box displays, as shown in [Figure 64](#).



Figure 64: Director Firmware Library dialog box

4. The firmware version displays at the lower left corner of the dialog box in WW.XX.YY.ZZ format, where:
 - WW is the version level
 - XX is the release level
 - YY is the patch level
 - ZZ is the build level
5. Click **Close**.

Adding a Firmware Version

The firmware version shipped with the director is provided on the Director documentation CD. Subsequent firmware versions to upgrade the director are provided to customers through the Hewlett-Packard website.

Note: When adding a firmware version, follow procedural information in the release notes that accompany the firmware version. This information supplements information provided in this general procedure.

Use these steps to add a director firmware version to the library stored on the HAFM appliance hard drive:

1. Obtain the new firmware version from the Hewlett-Packard website:

Note: The following path is subject to change.

- a. At the HAFM appliance or other personal computer (PC) with Internet access, open the Hewlett-Packard website. The uniform resource locator (URL) is <http://www.hp.com/country/us/eng/support.html>.
 - b. Click on **Firmware Downloads** in left panel.
 - c. Click the **Director Firmware Version XX.YY.ZZ** entry, where **XX.YY.ZZ** is the desired version. The Windows Save As dialog box displays.

Verify or correct the directory path specified in the **Save in** field and the file name specified in the **File name** field.
 - d. Click **Save**. The new firmware version is downloaded and saved to the HAFM appliance or PC hard drive.
 - e. If the new firmware version was downloaded to a PC (not the HAFM appliance), transfer the firmware version file to the HAFM appliance by backup disk, CD-ROM, or other electronic means.
2. Open the *HAFM* application. The View All - HAFM 8 main window displays.
 3. Double-click the icon representing the director to which the firmware version will be added. The **Hardware View** page for the selected director displays.

4. Choose **Maintenance > Firmware Library**. The Director Firmware Library dialog box displays, as shown in [Figure 64](#).
5. Click **New**. The New Firmware Version dialog box displays, as shown in [Figure 65](#).




Figure 65: New Firmware Version dialog box

6. Select the desired firmware version file (downloaded in [step 1](#)) from the HAFM appliance backup drive, CD-ROM drive, or hard drive. Verify that the correct directory path and filename display in the **File name** field and click **Save**. The New Firmware Description dialog box displays. See [Figure 66](#).



Figure 66: New Firmware Description dialog box

7. Enter a description (up to 24 characters in length) for the new firmware version and click **OK**. It is recommended the description include the installation date and text that uniquely identifies the firmware version.
8. A Transfer Complete message box displays indicating the new firmware version is stored on the HAFM appliance hard drive. Click **Close** to close the message box.

The new firmware version and associated description display in the Director Firmware Library dialog box.

9. Click **Close**.
10. To send the firmware version to a director, see [“Downloading a Firmware Version to a Director”](#) on page 123.

Modifying a Firmware Version Description

Use these steps to modify the description of a director firmware version in the library stored on the HAFM appliance hard drive:

1. Open the *HAFM* application. The View All - HAFM 8 main window displays.
2. Double-click the icon representing the director for which the firmware version description will be modified. The **Hardware View** page for the selected director displays.
3. Choose **Maintenance > Firmware Library**. The Director Firmware Library dialog box displays, as shown in [Figure 64](#).
4. Select the firmware version to be modified and click **Modify**. The Modify Firmware Description dialog box displays.
5. Enter a modified description (up to 24 characters in length) for the firmware version and click **OK**. It is recommended the description include the installation date and text that uniquely identifies the firmware version.
The new description for the firmware version displays in the Director Firmware Library dialog box.
6. Click **Close**.

Deleting a Firmware Version

Use these steps to delete a firmware version from the library stored on the HAFM appliance hard drive:

1. Open the *HAFM* application. The View All - HAFM 8 main window displays.
2. Double-click the icon representing the director from which the firmware version will be deleted. The **Hardware View** page for the selected director displays.
3. Choose **Maintenance > Firmware Library**. The Director Firmware Library dialog box displays, as shown in [Figure 64](#).
4. Select the firmware version to be deleted and click **Delete**. A confirmation dialog box displays.
5. Click **OK**. The selected firmware version is deleted from the Director Firmware Library dialog box.
6. Click **Close**.

Downloading a Firmware Version to a Director

This procedure downloads a selected firmware version from the HAFM appliance library to a director managed by the open instance of the Element Manager. The procedure applies to a director with two (redundant) CTP2 cards. The process occurs concurrently without taking the director offline or disrupting operation. The new firmware version takes effect when control is passed from the active to the backup CTP2 card. Although director operation is not affected, name server, alias server, and login server functions are momentarily unavailable during CTP2 card switchover. Although traffic is not disrupted, the green port LEDs will flicker or blink during the IPL portion of this operation as control is passed to the other CTP2 card.

Note: When downloading a firmware version, follow procedural information in the release notes that accompany the firmware version. This information supplements information provided in this general procedure.

Use these steps to download a firmware version to a director:

1. Open the *HAFM* application. The View All - HAFM 8 main window displays.
2. Before downloading firmware version *XX.YY.ZZ* to a director, ensure the required, compatible version of the *HAFM* application is running on the HAFM appliance. Refer to the release notes that shipped with HAFM.
 - a. Choose **Help >About**. The About dialog box displays and lists the *HAFM* application version. Click **OK** to close the dialog box.
 - b. If required, install the correct version of the *HAFM* application.
3. Double-click the icon representing the director to which the firmware version will be downloaded. The **Hardware View** page for the selected director displays.
4. As a precaution to preserve director configuration information, complete the data collection procedure as follows:
 - a. Open the *HAFM* application. The View All - HAFM 8 main window displays.
 - b. Double-click the icon representing the director for which the configuration file will be backed up. The **Hardware View** page for the selected director displays.

- c. Choose **Maintenance > Backup & Restore Configuration**. The Backup and Restore Configuration dialog box displays, as shown in [Figure 67](#).




Figure 67: Backup and Restore Configuration dialog box

- d. Click **Backup**. When the backup process finishes, the Backup Complete dialog box displays.
 - e. Click **OK** to close the dialog box and return to the **Hardware View** page.
5. Choose **Maintenance > Firmware Library**. The Director Firmware Library dialog box displays, as shown in [Figure 64](#).
6. Select the firmware version to be downloaded and click **Send**. The send function verifies existence of certain director conditions before the download process begins. If an error occurs, a message displays indicating the problem must be fixed before firmware is downloaded. Conditions that terminate the process include:
 - A redundant CTP2 card failure.
 - The firmware version is being installed on the director by another user.
 - The director-to-HAFM appliance link is down.

If a problem occurs and a corresponding message displays, refer to the *HP StorageWorks Director 2/64 Service Manual* for specific information on isolating the problem. If no error occurs, the Send Firmware confirmation box displays.

7. Click **Yes**. The Send Firmware dialog box displays.

As the download begins, a "Writing data to FLASH" message displays at the top of the dialog box, followed by a "Sending Files" message. This message remains as a progress bar travels across the dialog box to show percent completion of the download. The bar progresses to 50% when the last file is transmitted to the first CTP2 card. The bar remains at the 50% point until the director performs an Initial Program Load (IPL) (indicated by an "IPLing" message). During the IPL, the director-to-HAFM appliance link drops momentarily and the following occurs at the Element Manager:

- As the network connection drops, the director Status table turns yellow, the **Status** field displays No Link, and the **State** field displays a reason message.
- The alert panel at the bottom of the navigation control panel displays a gray square, indicating director status is unknown.
- Illustrated FRUs in the **Hardware View** page are removed, and then displayed again as the connection is re-established.

After the IPL, a “Synchronizing CTP2s” message displays. This message remains as files are transmitted to the second CTP2 card and the progress bar travels across the dialog box to 100%. When the download reaches 100%, a “Send firmware complete” message displays.

8. Click **Close** to close the dialog box.
9. Click **Close**.

Backing Up the Director's Configuration

Use these steps to back up the configuration file to the HAFM appliance:

1. Open the *HAFM* application. The View All - HAFM 8 main window displays.
2. Double-click the icon representing the director for which the configuration file will be backed up. The **Hardware View** page for the selected director displays.
3. Choose **Maintenance > Backup & Restore Configuration**. The Backup and Restore Configuration dialog box displays, as shown in [Figure 67](#).
4. Click **Backup**. When the backup process finishes, the Backup Complete dialog box displays.
5. Click **OK**.

Regulatory Compliance Notices



This appendix covers the following topics:

- [Regulatory Compliance ID Numbers](#), page 128
- [Federal Communications Commission Notice](#), page 128
- [IEC EMC Statement \(Worldwide\)](#), page 130
- [Spécification ATI Classe A \(France\)](#), page 130
- [Canadian Notice \(Avis Canadien\)](#), page 131
- [European Union Notice](#), page 131
- [Japanese Notice](#), page 132
- [Harmonics Conformance \(Japan\)](#), page 132
- [German Noise Declaration](#), page 132
- [Laser Safety](#), page 133
- [Declaration of Conformity](#), page 134

Regulatory Compliance ID Numbers

For the purpose of regulatory compliance certifications and identification, your HP StorageWorks Director is assigned a Hewlett-Packard Regulatory Model Number. The Hewlett-Packard Regulatory Model Number for this product is:

RSVLB-0211

The HP StorageWorks Director Regulatory Model Number can be found on the product label, along with the required approval markings and information. When requesting certification information for this product, always refer to this Regulatory Model Number. This Regulatory Model Number should not be confused with the marketing name or product number for your HP StorageWorks Director.

Federal Communications Commission Notice

Part 15 of the Federal Communications Commission (FCC) Rules and Regulations has established Radio Frequency (RF) emission limits to provide an interference-free radio frequency spectrum. Many electronic devices, including computers, generate RF energy incidental to their intended function and are, therefore, covered by these rules. These rules place computers and related peripheral devices into two classes, A and B, depending upon their intended installation. Class A devices are those that may reasonably be expected to be installed in a business or commercial environment. Class B devices are those that may reasonably be expected to be installed in a residential environment (for example, personal computers). The FCC requires devices in both classes to bear a label indicating the interference potential of the device as well as additional operating instructions for the user.

The rating label on the device shows the classification (A or B) of the equipment. Class B devices have an FCC logo or FCC ID on the label. Class A devices do not have an FCC logo or ID on the label. After the class of the device is determined, refer to the corresponding statement in the following sections.

Class A Equipment

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at personal expense.

Class B Equipment

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or television technician for help.

Declaration of Conformity for Products Marked with FCC Logo—United States Only

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For questions regarding your product, refer to <http://www.hp.com>.

For questions regarding this FCC declaration, contact:

Hewlett-Packard Company
Product Regulations Manager
3000 Hanover St.
Palo Alto, CA 94304

Or call 1-650-857-1501

To identify this product, refer to the part, Regulatory Model Number, or product number found on the product.

Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Hewlett-Packard Company may void the user's authority to operate the equipment.

Network and Serial Cables

Connections to this device must be made with shielded cables with metallic RFI/EMI connector hoods in order to maintain compliance with FCC Rules and Regulations.

IEC EMC Statement (Worldwide)

This is a Class A product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

Spécification ATI Classe A (France)

DECLARATION D'INSTALLATION ET DE MISE EN EXPLOITATION d'un matériel de traitement de l'information (ATI), classé A en fonction des niveaux de perturbations radioélectriques émis, définis dans la norme européenne EN 55022 concernant la Compatibilité Electromagnétique.

Canadian Notice (Avis Canadien)

Class A Equipment

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Class B Equipment

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

European Union Notice

Products with the CE Marking comply with both the EMC Directive (89/336/EEC) and the Low Voltage Directive (73/23/EEC) issued by the Commission of the European Community.

Compliance with these directives implies conformity to the following European Norms (the equivalent international standards are in parenthesis):

- EN55022 1998 (CISPR 22)-Electromagnetic Interference
- EN55024 1998 (IEC61000-4-2, IEC61000-4-3, IEC61000-4-4, IEC61000-4-5, IEC61000-4-6, IEC61000-4-8, IEC61000-4-11)-Electromagnetic Immunity
- EN60950 (IEC60950)-Product Safety
- Power Quality: (IEC61000-3-2)-Harmonics and (IEC61000-3-3)-Voltage Fluctuations and Flicker
- Also approved under UL 1950, 3rd Edition/CSA C22.2 No. 950-95, Safety of Information Technology Equipment

Japanese Notice

ご使用になっている装置にVCCIマークが付いていましたら、次の説明文をお読み下さい。

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。
取扱説明書に従って正しい取り扱いをして下さい。

VCCIマークが付いていない場合には、次の点にご注意下さい。

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

Harmonics Conformance (Japan)

高調波ガイドライン適合品

German Noise Declaration

Schalldruckpegel L_p = 68.8 dB(A)
Am Arbeitsplatz (operator position)
Normaler Betrieb (normal operation)
Nach ISO 7779:1988 / EN 27779:1991 (Typprüfung)

Laser Safety



WARNING: To reduce the risk of exposure to hazardous radiation:

- Do not try to open the laser device enclosure. There are no user-serviceable components inside.
- Do not operate controls, make adjustments, or perform procedures to the laser device other than those specified herein.
- Allow only Hewlett-Packard authorized service technicians to repair the laser device.

Certification and Classification Information

This product contains a laser internal to the Optical Link Module (OLM) for connection to the Fibre communications port.


In the USA, the OLM is certified as a Class 1 laser product conforming to the requirements contained in the Department of Health and Human Services (DHHS) regulation 21 CFR, Subchapter J. The certification is indicated by a label on the plastic OLM housing.

Outside the USA, the OLM is certified as a Class 1 laser product conforming to the requirements contained in IEC 825-1:1993 and EN 60825-1:1994, including Amendment 11:1996.

The OLM includes the following certifications:



- UL Recognized Component (USA)
- CSA Certified Component (Canada)
- TUV Certified Component (European Union)
- CB Certificate (Worldwide)

The following figure shows the Class 1 information label that appears on the metal cover of the OLM housing:



Declaration of Conformity

The Declaration of Conformity is shown below:

 DECLARATION OF CONFORMITY According to ISO/IEC Guide 22 and EN 45014	
Manufacturer's Name:	Hewlett-Packard Company Network Storage Solutions
Manufacturer's Address:	8000 Foothills Blvd. Roseville, CA, 95747 USA
Declares, that the product	
Product Name:	hp StorageWorks director 2/64
Product Number:	A6534B and A6534BZ
Regulatory Model Number:	RSVLB-0211
Product Options:	All
Conforms to the following Product Specifications:	
Safety:	IEC 60950:1991+A1+A2+A3+A4 / EN 60950:1992+A1+A2+A3+A4+A11 GB 4943-1995 IEC 60825-1:1993 / EN 60825-1:1994+A11, Class 1 (Laser/LED)
EMC:	CISPR 22:1997 / EN 55022:1996+A1 Class A ¹ GB 9254-1998 CISPR 24:1997 / EN 55024:1998 IEC 61000-3-2:1995 / EN 61000-3-2:1995+A14 IEC 61000-3-3:1994 / EN 61000-3-3:1995
Supplementary Information:	
The product herewith complies with the requirements of the Low Voltage Directive 73/23/EEC and the EMC Directive 89/336/EEC and carries the CE-marking accordingly.	
1) The Product was tested in a worst-case configuration which maximizes RFI emissions.	
Roseville, CA, USA June 12, 2002	 George E. Bairrett, Regulatory Mgr.
<small>European contact for regulatory topics only: Hewlett-Packard GmbH, HQ-TRE, Hammerberg-Strasse 140, D-71034 Böblingen (FAX: +49-7141-14-3142)</small>	

Technical Specifications



This appendix contains the following information:

- [Physical Dimensions](#), page 136
- [Environmental Specifications](#), page 136
- [Power Requirements](#), page 137
- [Operating Tolerances](#), page 137
- [Laser Information](#), page 137

Physical Dimensions

[Table 7](#) lists Director 2/64 dimensions.

Table 7: Dimensions

Dimension	Size
Height	39.7 cm (15.7 in)
Width	44.5 cm (17.5 in)
Depth	54.6 cm (21.5 in)
Weight	52.3 kg (115 lb)
Shipping Weight	76.4 kg (168 lb)

Environmental Specifications

[Table 8](#) lists environmental ranges for shipping, storing, and operating the HP StorageWorks Director 2/64.

Table 8: Environmental Specifications

Specification	Shipping	Storage	Operating
Weight	76.4 kg (168 lb)	52.3 kg (115 lb)	52.3 kg (115 lb)
Temperature	−40°F to 140°F (40°C to 60 °C)	34°F to 140°F (1°C to 60 °C)	40°F to 104°F (4°C to 40 °C)
Humidity	5% to 100%	5% to 80%	8% to 80%
Maximum wet-bulb temperature	84°F (29°C)	84°F (29°C)	81°F (27°C)
Altitude	40,000 ft (12,192 km)	40,000 ft (12,192 km)	10,000 ft (3,048 km)

Power Requirements

Table 9 lists Director 2/64 power requirements.

Table 9: Power Requirements

Specification	Value
Input voltage	100 to 120 or 200 to 240 VAC
Input frequency	50/60 Hz

Operating Tolerances

Table 10 lists heating and cooling specifications, shock and vibration tolerances, acoustical noise, and inclination.

Table 10: Operating Tolerances

Specification	Value
Heat dissipation	16 UPM cards (maximum): 490W (1,672 BTU/hr)
Cooling airflow clearances	Right and left sides: 5.1 cm (2.0 in) Front and rear: 7.6 cm (3.0 in) Top and bottom: No clearance required
Shock and vibration tolerance	60 Gs for 10 milliseconds without non-recoverable errors
Acoustical noise	6.9 Bels
Inclination	10° maximum

Laser Information

Three configurations of cards with fixed optics will be provided for each of the connector types: four extended long-wave ports, four long-wave ports, and four short-wave ports. Table 11 lists the 2 Gb laser specifications.

Table 11: Laser specs - 2 Gb

Part Number	Transceivers on UPM Card	Wave Length	Media/Distance	Standard
300836-B21 Long wave - 35 Km	4 Extended Long wave	1310 nm	9/125 μ m Single-mode: 1 m–35 Km	100-SM-LL-L
300835-B21 Long wave - 10 Km	4 Long wave	1310 nm	9/125 μ m Single-mode: 1 m–10 Km	100-SM-LL-L
300834-B21 Short wave	4 Short wave	850 nm	50/125 μ m Multi-mode: 2 m–500 m 62.5/125 μ m Multi-mode: 1 m–200 m	100-M5-SN-I

Electrostatic Discharge



This appendix contains the following information:

- [Precautions Against Electrostatic Discharge](#), page 140
- [Grounding Methods](#), page 140

Precautions Against Electrostatic Discharge

To prevent damaging the system, be aware of the precautions you need to follow when setting up the system or handling parts. A discharge of static electricity from a finger or other conductor may damage system boards or other static-sensitive devices. This type of damage may reduce the life expectancy of the device.

To prevent electrostatic damage, observe the following precautions:

- Avoid hand contact by transporting and storing products in static-safe containers.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free workstations.
- Place parts on a grounded surface before removing them from their containers.
- Avoid touching pins, leads, or circuitry.
- Always make sure you are properly grounded when touching a static-sensitive component or assembly.

Grounding Methods

There are several methods for grounding. Use one or more of the following methods when handling or installing electrostatic-sensitive parts:

- Use a wrist strap connected by a ground cord to a grounded workstation or computer chassis. Wrist straps are flexible straps with a minimum of 1 megohm (± 10 percent) resistance in the ground cords. To provide proper ground, wear the strap snug against the skin.
- Use heel straps, toe straps, or boot straps at standing workstations. Wear the straps on both feet when standing on conductive floors or dissipating floor mats.
- Use conductive field service tools.
- Use a portable field service kit with a folding static-dissipating work mat.

If you do not have any of the suggested equipment for proper grounding, have a Hewlett-Packard authorized service provider install the part.

Note: For more information on static electricity, or for assistance with product installation, contact a Hewlett-Packard authorized service provider.

A

AIX operating system [112](#)
 alerts, introduction [20](#)
 allen wrench, caution [31](#)
 asynchronous RS-232
 null modem cable [32](#)
 audience [12](#)
 authorized reseller, HP [16](#)

B

backing up director configuration file [126](#)
 bb_credit [92](#)
 beaconing, introduction [21](#)

C

cable management assembly [26](#)
 cables, FCC compliance statement [130](#)
 call-home feature
 introduction [20](#)
 Canadian Notice (Avis Canadien) [131](#)
 carton contents [44](#)
 CE marking [131](#)
 CFR, laser compliance [27](#)
 changing the director's IP address [71](#)
 class 1 laser transceivers [27](#)
 clock speed, processor [112](#)
 Code of Federal Regulations [27](#)
 COMn properties dialog box [73](#)
 components of the director [24](#)
 configuration data, backing up [107](#)
 configure director network information [70](#)
 configure fabric parameters dialog box [91](#)

configure feature key dialog box
 procedure [107](#)
 configure HAFM appliance [107](#)
 configure menu
 features [107](#)
 HAFM appliance [107](#)
 configure menu, enable telnet [108](#)
 configure switch parameters dialog box [87](#), [88](#)
 configuring
 ethernet events [100](#)
 fabric operating parameters [91](#)
 feature key [107](#)
 port addresses, FICON [96](#)
 connecting the director to the LAN segment [77](#)
 connectivity failures, causes of [22](#)
 conventions
 document [13](#)
 equipment symbols [14](#)
 text symbols [13](#)
 CTP cards, description [25](#)

D

data collection [21](#)
 declaration of conformity [129](#)
 default
 Windows 2000 password [114](#)
 Windows 2000 user name [114](#)
 default IP address [70](#)
 defaults
 switch priority setting [93](#)
 degraded fabric performance, causes of [22](#)
 diagnostic software, introduction [20](#)
 dialog boxes

- configure fabric parameters [91](#)
- configure feature key
 - procedure [107](#)
- configure switch parameters [87, 88](#)
- director
 - e_d_tov [23](#)
 - fibre channel addresses [88](#)
 - firmware [119](#)
 - general description [18](#)
 - hardware components [24](#)
 - installation tools required [46](#)
 - management, overview [19](#)
 - NV-RAM [87, 91](#)
 - r_a_tov [23](#)
 - rerouting delay [89](#)
 - tools supplied [31](#)
- director 2/64
 - installing [46](#)
- director 2/64 shipping carton
 - items [41](#)
- director firmware
 - adding version [119](#)
 - deleting a version [122](#)
 - downloading [123](#)
 - version [118](#)
- director firmware library dialog box [118](#)
- document
 - conventions [13](#)
 - related documentation [12](#)
- domain ID [23](#)
 - insistent [89](#)
 - preferred [88](#)
- domain RSCNs [90](#)
- downloading firmware [123](#)

E

- e_d_tov [92](#)
 - fabric segmentation [92](#)
 - incompatible parameters [23](#)
 - less than r_a_tov [92](#)
 - multi-switch fabrics [92](#)
 - rerouting delay [90](#)

- E_port segmentation
 - preferred domain ID [89](#)
- e_port segmentation [23](#)
 - causes of [23](#)
- e_ports [27](#)
- electrostatic discharge precautions [140](#)
- e-mail notification
 - introduction [20](#)
- enable telnet [108](#)
- equipment symbols [14](#)
- ESD
 - wrist strap [33](#)
- Ethernet
 - hub
 - unpacking, inspecting, and installing [111](#)
- ethernet
 - events, configure at HAFM appliance [100](#)
 - events, enable at HAFM appliance [100](#)
- ethernet network adapter [113](#)
- European Union notice [131](#)

F

- f_ports [27](#)
- fabric parameters
 - bb_credit [92](#)
 - e_d_tov [92](#)
 - interop mode [93](#)
 - r_a_tov [92](#)
 - switch priority [93](#)
- fabric segmentation
 - e_d_tov [92](#)
 - preferred domain ID [89](#)
- failover, SBAR assembly [30](#)
- FC fabric element MIB, version [21](#)
- FCC
 - class A compliance notice [129](#)
 - class B compliance notice [129](#)
- FCC compliance statement, cables [130](#)
- feature key [107](#)
 - configuring [107](#)
- features of the director [24](#)

Federal Communications Commission (FCC)
notice [128](#)

fiber optic
cleaning kit [34](#)
protective plug [32](#)

Fibre Alliance MIB [21](#)

fibres channel addresses [88](#)

Fibre Channel ports
connecting cables [109](#)

FICON
port addresses, configuring [96](#)
FICON devices, communication [86](#)
FICON management server [87](#), [107](#)
FICON management style
FICON management server [87](#)

firmware
deleting version [122](#)
determining version [118](#)
modifying description [121](#)
release notes [119](#)

firmware library [118](#)

frames
routing of [89](#)

front bezel [26](#)

FRUs, CTP card [25](#)

G

g_ports [27](#)
UPM card [27](#)
getting help [16](#)
grounding methods [140](#)

H

HA PA-RISC processor [112](#)

HAFM
configuring ports [94](#)
configuring SNMP trap message recipients
[96](#)
enabling e-mail notification [97](#)
enabling to manage the director [78](#)
remote location [112](#)

remote location requirements [112](#)
setting offline [85](#)
setting the director online [85](#)

HAFM 8
login dialog box [114](#)

HAFM appliance
Fibre Alliance MIB [21](#)
name [114](#)

hard drives, remote workstation [112](#)
help, obtaining [16](#)

Hewlett-Packard rack installation [54](#)

hexagonal adapter [31](#)

High Availability Fabric Manager
login dialog box [114](#)

homogeneous fabric
interop mode [94](#)

hop counts [89](#)

HP
authorized reseller [16](#)
storage web site [16](#)
technical support [16](#)

HP 9000 series rack installation [47](#)

HP-UX operating system [112](#)

HyperTerminal [33](#), [74](#)

I

inband switch management [87](#)

insistent domain ID [88](#), [89](#)

installation
Hewlett-Packard rack [54](#)
HP 9000 series rack [47](#)
requirements [37](#)
tools required [46](#)

installation options [36](#)
customer-supplied equipment rack [36](#)
table or desk top [36](#)

installation tasks
backing-up configuration data [107](#)
unpacking, inspecting, and installing
Ethernet hub [111](#)

installing
cage nuts [50](#)

- mounting hardware [49, 60](#)
- positioning the director in the rack [51, 61](#)
- shelf brackets [47, 55](#)
- tips [46](#)
- installing rear angle brackets [52](#)
- Intel Pentium processor [112](#)
- Internet Explorer [113](#)
- interop mode [93](#)
 - homogeneous fabric [94](#)
 - open fabric 1.0 [94](#)
- interswitch link, g_port [27](#)
- IP address [70](#)
- ISL, g_port [27](#)
- items
 - director 2/64 shipping carton [41](#)

L

- laser
 - devices [133](#)
 - information [134](#)
- laser transceivers [27](#)
- LEDs
 - front bezel [26](#)
 - power supplies [27](#)
 - SBAR assembly [30](#)
 - UPM card [28](#)
- lift device [46](#)
- Linux operating system, version [112](#)
- localhost, HAFM appliance name [114](#)
- logic card, torque tool, caution [31](#)
- logs, introduction [20](#)
- long-wave laser transceivers [28](#)
- loopback plug
 - multi-mode [32](#)
 - single-mode [32](#)

M

- MAC address [70](#)
- maintenance port [20, 30, 31](#)
- management server
 - FICON [107](#)

- open systems [107](#)
- management style
 - FICON [87](#)
 - open systems [87](#)
- managing
 - director [19](#)
- memory, remote workstation [113](#)
- MIBs [21](#)
- Microsoft Internet Explorer [113](#)
- mode
 - interop [93](#)
- multi-mode fiber optic cables [28](#)
- multi-switch fabric [22](#)
 - connectivity failures, causes of [22](#)
 - degraded performance, causes of [22](#)
 - domain IDs [23](#)
 - e_d_tov [92](#)
 - e_port segmentation
 - causes of [23](#)
 - principal switch [93](#)
 - rerouting delay [89](#)
 - zoning [23](#)
- multi-switch fabric, e_ports [27](#)

N

- n_ports [27](#)
- Netscape Navigator [113](#)
- network addresses
 - changing [71](#)
 - default settings [70](#)
 - gateway [70](#)
 - IP address [70](#)
 - MAC address [70](#)
 - subnet mask [70](#)
- null modem cable [32](#)
- NV-RAM [87, 91](#)

O

- OFC class 1 laser transceivers [27](#)
- online state, setting [85](#)
- open fabric 1.0

- interop mode [94](#)
- open systems management server [107](#)
- open systems management style [87](#)
- optional kits
 - combination long-wave/short-wave port module kit [34](#)
 - short-wave port module kits [34](#)
- OSI devices, communication [86](#)

P

- password
 - default Windows 2000 [114](#)
- PDU [53](#), [63](#)
- port addresses, FICON, configuring [96](#)
- port loopback diagnostic tests, fiber optic
 - loopback plug [32](#)
- POST [68](#)
- power module assembly [30](#)
- power supplies [26](#)
- power supply requirements [137](#)
- power switch [30](#), [31](#)
- POWER3 microprocessor [112](#)
- power-on self test [68](#)
- PowerPC microprocessor [112](#)
- precautions against electrostatic discharge [140](#)
- preferred domain ID [88](#)
 - multi-switch fabric [88](#)
- principal switch, determining [93](#)
- ProComm Plus [33](#)
- product manager
 - SNMP agent [19](#)
- protective plug [32](#)

R

- r_a_tov [92](#)
 - greater than e_d_tov [92](#)
 - incompatible parameters [23](#)
- rack stability, warning [15](#)
- rear angle brackets [51](#)
- Regulatory Compliance identification numbers [128](#)

- regulatory compliance notices [127](#)
- related documentation [12](#)
- release notes [119](#)
- rerouting delay [89](#)
- RFC 1213
 - definition [21](#)

S

- safety
 - ESD grounding cable with wrist strap [33](#)
 - fiber optic protective plug [32](#)
- SANtegrity Binding features
 - switch binding [94](#)
- SBAR assembly [30](#)
- segmentation
 - causes of [23](#)
- serviceability features [20](#)
- set director date and time manually [82](#)
- setting, online state [85](#)
- shelf brackets [47](#), [55](#)
- shortwave laser transceivers [28](#)
- single-mode fiber optic cables [28](#)
- site plan [37](#)
- SNMP agent
 - general description [19](#)
- SNMP trap messages
 - maximum recipients [21](#)
- Solaris operating system [112](#)
- SunOS operating system [112](#)
- suppress RSCNs on zone set activations [90](#)
- switch
 - error-detection, reporting, and serviceability features [20](#)
 - multi-switch fabric [22](#)
- switch binding [94](#)
- switch parameters
 - domain RSCNs [90](#)
 - insistent domain ID [89](#)
 - NV-RAM storage [87](#), [91](#)
 - preferred domain ID [88](#)
 - rerouting delay [89](#)
 - suppress RSCNs on zone set activations [90](#)

- switch priority [93](#)
 - related number codes [93](#)
- switch priority setting [93](#)
- switches, principal, determining [93](#)
- symbols in text [13](#)
- symbols on equipment [14](#)
- synchronize date and time [82](#)

T

- TCP/IP MIB-II
 - definition [21](#)
- technical specifications, power requirements [137](#)
- technical support, HP [16](#)
- telnet, enabling [108](#)
- text symbols [13](#)
- tips for installing [46](#)
- tools
 - supplied by service personnel [33](#)
 - supplied with director [31](#)
- tools required to install a director [46](#)
- torque tool [31](#)
 - caution [31](#)
- trap messages
 - maximum recipients [21](#)

U

- UltraSPARC-II processor [112](#)
- UNIX workstation, specifications [112](#)
- UPM cards [27](#)
- user name
 - default Windows 2000 [114](#)

V

- versions
 - AIX operating system [112](#)

- director firmware [19](#)
- FC fabric element MIB [21](#)
- firmware
 - deleting [122](#)
 - determining [118](#)
 - modifying description [121](#)
- HP-UX operating system [112](#)
- Internet Explorer [113](#)
- Linux operating system [112](#)
- Netscape Navigator [113](#)
- Solaris operating system [112](#)
- SunOS operating system [112](#)
- Windows operating systems [33](#), [112](#)
- video card, remote workstation [113](#)
- voltage, AC power connectors [30](#), [31](#)

W

- warning
 - rack stability [15](#)
 - symbols on equipment [14](#)
- web server, overview [19](#)
- web sites
 - HP storage [16](#)
- Windows 2000
 - default password [114](#)
 - default user name [114](#)
- Windows operating systems, versions [33](#), [112](#)
- workstation, UNIX [112](#)
- WWN
 - principal switch [93](#)

Z

- zone set, description of [22](#)
- zoning
 - joining, rules of [23](#)